



Office: (800) 683-7248

Technical Support: (702) 651-3444

FAX: (702) 651-0214

E-Mail: [techsupport@jcmglobal.com](mailto:techsupport@jcmglobal.com)


Web-Site: [www.jcmglobal.com](http://www.jcmglobal.com)

# UBA<sup>®</sup> Series

## Universal Bill Acceptor

### (UBA-1x-SS & UBA-x4-SS/SU)

*Operation and Maintenance Manual  
(Revision 3)*



**JCM Part No. 960-000097R\_Rev. 3**



© 2010, JCM American, Corporation

| REVISION HISTORY |          |   |         |
|------------------|----------|---|---------|
| Rev No.          | Date     | Reason for Update   | Comment |
| A                | 6/16/05  | <b>Initial Version</b>  |         |
| 1                | 10/26/06 | <b>Updated Initial Version</b>  |         |
| 2                | 12/19/07 | <b>Updated Revision 1 Version</b>   |         |
| 3                | 2/23/10  | <b>Updated Revision 2 Version with Additional UBA14/24 &amp; 25 Information</b> |         |
| 4                |          |   |         |
| 5                |          |   |         |

JCM is a registered trademark of JCM American Corporation. All other product names mentioned herein may be registered trademarks or trademarks of their respective companies. Furthermore,™, ® and © are not always mentioned in each case throughout this publication.

# UBA-1x-SS & UBA-x4-SS/SU Series

## Table of Contents

| TOC  | Page        |
|--|-------------|
| <b>1 GENERAL INFORMATION .....</b>   | <b>1-1</b>  |
| <b>Model/Type Number Specifications .....</b>                                  | <b>1-2</b>  |
| <b>Precautions .....</b>   | <b>1-2</b>  |
| User Cautions.....   | 1-2         |
| <b>UBA-10/11/12 Component Names .....</b>                                      | <b>1-3</b>  |
| <b>UBA-14/24 Component Names .....</b>   | <b>1-4</b>  |
| <b>Specifications .....</b>  | <b>1-5</b>  |
| Technical Specifications .....   | 1-5         |
| Environmental Specifications .....   | 1-5         |
| Electrical Specifications .....  | 1-5         |
| Structural Specifications .....  | 1-5         |
| <b>System Configuration .....</b>  | <b>1-6</b>  |
| <b>Primary Features .....</b>  | <b>1-6</b>  |
| <b>Standard Unit Dimensions .....</b>  | <b>1-8</b>  |
| <b>UBA-1x Unit Dimensions with ICB .....</b>                                   | <b>1-10</b> |
| <b>UBA-x4-SS Unit Dimensions .....</b>   | <b>1-11</b> |
| <b>UBA-x4-SU Unit Dimensions .....</b>   | <b>1-12</b> |
| <b>Standard Cash Box Dimensions .....</b>                                      | <b>1-13</b> |
| <b>Large Cash Box Dimensions .....</b>   | <b>1-14</b> |
| <b>Country Codes .....</b>   | <b>1-15</b> |
| <b>Technical Contact Information .....</b>                                     | <b>1-17</b> |
| Americas & Oceania.....  | 1-17        |
| JCM American Corporation.....  | 1-17        |
| Europe, Africa, Russia & Middle East .....                                     | 1-17        |
| JCM Europe GmbH.....   | 1-17        |
| UK & Ireland .....   | 1-17        |
| JCM United Kingdom Ltd.....  | 1-17        |
| Asia .....   | 1-17        |
| JCM Gold (HK) Ltd.....   | 1-17        |
| Japan Cash Machine Co, Limited (HQ) .....                                      | 1-17        |
| <b>2 INSTALLATION/OPERATION .....</b>  | <b>2-1</b>  |
| <b>Installation .....</b>  | <b>2-1</b>  |
| <b>Lock Installation .....</b>   | <b>2-2</b>  |
| <b>DIP Switch Configurations .....</b>   | <b>2-2</b>  |
| <b>Connector Pin Assignments .....</b>   | <b>2-3</b>  |
| Connector Pin Assignments (Continued 1) .....                                  | 2-4         |
| Connector Pin Assignments (Continued 2) .....                                  | 2-5         |
| Connector Pin Assignments (Continued 3) .....                                  | 2-6         |
| <b>Optional Conversion Circuit Boards and Harnesses .....</b>                  | <b>2-6</b>  |
| UBA 10/11/12-SS Optional Conversion Circuit Board .....                        | 2-6         |
| UBA 14/24-SS Optional Conversion Circuit Board.....                            | 2-6         |
| Optional Conversion Circuit Board Installation Procedure .....                 | 2-6         |
| Optional Conversion Board and Harness Kits .....                               | 2-7         |
| External Interface Connection Structure for an Optional Conversion Board ..... | 2-7         |
| <b>Optional USB Connector .....</b>  | <b>2-9</b>  |
| <b>Jumper Configurations .....</b>   | <b>2-9</b>  |

# Table of Contents

## Continued

|   | Page        |
|---|-------------|
| <b>Retrieving Banknotes .....</b>                               | <b>2-9</b>  |
| <b>Clearing a Banknote Jam .....</b>                            | <b>2-10</b> |
| <b>Cleaning/Preventive Maintenance .....</b>                    | <b>2-11</b> |
| <b>Available Cleaning Card .....</b>                            | <b>2-11</b> |
| Card Features .....   | 2-11        |
| Directions For Use .....  | 2-11        |
| <b>UBA 10/11/12/14 &amp; 24 Related Schematics .....</b>        | <b>2-12</b> |
| UBA Faceplate LED Lighting Control Circuit Schematic .....      | 2-12        |
| UBA Optional Conversion Board Interface Circuit Schematic ..... | 2-12        |
| UBA 10/11/12-SS Standard Interface Circuit Schematic .....      | 2-13        |
| UBA-14-SS Interface Circuit Schematic .....                     | 2-14        |
| External Input/Output Connector Circuit Schematic .....         | 2-15        |
| <b>Operational Flowcharts .....</b>                             | <b>2-17</b> |
| Operational Flowchart (Continued).....                          | 2-18        |
| <b>3 COMMUNICATIONS .....</b>                                   | <b>3-1</b>  |
| Americas & Oceania .....  | 3-1         |
| JCM American Corporation.....                                   | 3-1         |
| Europe, Africa, Russia & Middle East.....                       | 3-1         |
| JCM Europe GmbH.....  | 3-1         |
| UK & Ireland .....  | 3-1         |
| JCM United Kingdom Ltd.....                                     | 3-1         |
| Asia.....   | 3-1         |
| JCM Gold (HK) Ltd.....  | 3-1         |
| Japan Cash Machine Co, Limited (HQ) .....                       | 3-1         |
| <b>4 DISASSEMBLY/REASSEMBLY .....</b>                           | <b>4-1</b>  |
| <b>Tool Requirements .....</b>                                  | <b>4-1</b>  |
| <b>Primary Unit Disassembly .....</b>                           | <b>4-1</b>  |
| <b>Acceptor Unit Disassembly .....</b>                          | <b>4-1</b>  |
| Side and Top Cover Removal .....                                | 4-1         |
| Front Access Door Removal .....                                 | 4-2         |
| Opening Lever Disassembly .....                                 | 4-3         |
| Circuit Board Removal .....                                     | 4-3         |
| CPU Board Removal.....  | 4-3         |
| Upper Sensor Board Removal .....                                | 4-4         |
| Lower Sensor Board Removal .....                                | 4-4         |
| Transport Guides A, B, C, D, & E Disassembly .....              | 4-4         |
| Transport Guide A Disassembly .....                             | 4-4         |
| Transport Guides B & C Disassembly .....                        | 4-6         |
| Transport Guides D & E Disassembly .....                        | 4-7         |
| <b>Sensor Board Disassembly .....</b>                           | <b>4-7</b>  |
| Home Centering Sensor Board Disassembly .....                   | 4-7         |
| Encoder Sensor Board Disassembly .....                          | 4-7         |
| Anti-Pullback Home Sensor Board Disassembly .....               | 4-7         |
| <b>Transport Unit Motors Disassembly .....</b>                  | <b>4-8</b>  |
| Anti-Pullback Drive Motor Unit Disassembly .....                | 4-8         |
| Transport Motor Disassembly .....                               | 4-8         |
| Entrance Sensor Board Removal.....                              | 4-8         |
| Exit Sensor Board Disassembly.....                              | 4-9         |
| Centering Motor Unit Disassembly .....                          | 4-9         |

# Table of Contents

## Continued

|  | Page        |
|--|-------------|
| <b>Transport C Timing Belt</b>   |             |
| <b>Disassembly.....</b>  | <b>4-9</b>  |
| Transport C Timing Belt Removal .....  | 4-9         |
| Transport D Solenoid Removal .....   | 4-11        |
| Cash Box Handle and Intelligent Cash Box ICB Module Unit Disassembly.....              | 4-11        |
| Cash Box Handle Removal.....   | 4-11        |
| ICB Module Removal.....  | 4-11        |
| Cash Box Sensor Board Removal.....   | 4-12        |
| Pusher Mechanism Unit Disassembly.....   | 4-12        |
| <b>Final Timing Belt Disassembly.....</b>  | <b>4-12</b> |
| <b>5 WIRING DIAGRAMS.....</b>  | <b>5-1</b>  |
| <b>UBA Primary Components Parts Diagram .....</b>                                      | <b>5-1</b>  |
| <b>UBA-1x-SS SYSTEM WIRING DIAGRAM .....</b>   | <b>5-3</b>  |
| UBA-1X-SS System Wiring Diagram (Continued 1).....                                     | 5-5         |
| UBA-14/24 System Wiring Diagram (Continued 2).....                                     | 5-7         |
| UBA-14/24 System Wiring Diagram (Continued 3).....                                     | 5-9         |
| <b>6 PROGRAMMING, CALIBRATION &amp; TEST.....</b>                                      | <b>6-1</b>  |
| <b>Workbench Tool Requirements .....</b>   | <b>6-1</b>  |
| <b>Software Download Preparation .....</b>   | <b>6-1</b>  |
| <b>Software Downloading Procedure .....</b>  | <b>6-2</b>  |
| Program Installation .....   | 6-2         |
| Programming Instructions .....   | 6-3         |
| Forced Download Requirements.....  | 6-4         |
| <b>Calibration Procedures .....</b>  | <b>6-4</b>  |
| Calibration Description .....  | 6-4         |
| Calibration Tool Requirements .....  | 6-4         |
| When to Calibrate.....   | 6-5         |
| Initial Settings .....   | 6-5         |
| Adjustment Procedure .....   | 6-5         |
| <b>UBA-USB Tool Suite Overview.....</b>  | <b>6-7</b>  |
| Installing the UBA Tool Suite Application .....  | 6-8         |
| Installing the UBA Device Drivers .....  | 6-8         |
| Connecting the UBA Unit .....  | 6-8         |
| UBA USB Tool Suite Functions .....   | 6-9         |
| Download .....   | 6-9         |
| Statistics .....   | 6-9         |
| Sensor Adjustment .....  | 6-9         |
| <b>7 EXPLODED VIEWS AND PARTS LISTS .....</b>  | <b>7-1</b>  |
| <b>Entire UBA-10/11/12-SS &amp; 14/24/25-SS/SU Unit Views and Optional Parts .....</b> | <b>7-1</b>  |
| Entire UBA-10/11/12-SS Unit Parts List .....   | 7-2         |
| <b>Transport Unit Exploded Views.....</b>  | <b>7-3</b>  |
| Transport Unit Exploded Views (Continued 1) .....                                      | 7-4         |
| Transport Unit Exploded Views (Continued 2) .....                                      | 7-5         |
| Transport Unit Exploded Views (Continued 3) .....                                      | 7-6         |
| Transport Unit Parts List.....   | 7-7         |
| <b>UBA Frame Unit Exploded View .....</b>  | <b>7-12</b> |
| UBA-SS Cash Box Unit Exploded View .....   | 7-14        |
| UBA-SS Cash Box Unit Exploded View (Continued) .....                                   | 7-15        |
| UBA Cash Box Pusher Unit Mechanism Exploded View .....                                 | 7-16        |

# Table of Contents

## Continued

|   | Page        |
|---|-------------|
| Cash Box Unit Parts List.....                             | 7-18        |
| <b>Face Unit Exploded View.....</b>                       | <b>7-22</b> |
| Faceplate Unit Parts List.....                            | 7-23        |
| Optional Unit Parts List .....                            | 7-23        |
| <b>8 INDEX.....</b>                                       | <b>8-1</b>  |
| <b>A TROUBLESHOOTING .....</b>                            | <b>A-1</b>  |
| <b>Introduction .....</b>                                 | <b>A-1</b>  |
| <b>Troubleshooting Overview .....</b>                     | <b>A-1</b>  |
| <b>Fault Table Listings.....</b>                          | <b>A-1</b>  |
| <b>Performance Tests .....</b>                            | <b>A-5</b>  |
| Choosing and Selecting Operational Tests .....            | A-5         |
| No. 1 Transport Motor Forward/Reverse Rotation Test ..... | A-5         |
| No. 2 Stacker Test.....                                   | A-5         |
| No. 3 Running Test .....                                  | A-6         |
| No. 4 Anti-Pullback Mechanism Test.....                   | A-8         |
| No. 5 Centering Mechanism Test.....                       | A-8         |
| No. 6 Solenoid Test.....                                  | A-9         |
| No. 7 General Sensor Test.....                            | A-9         |
| No. 8 Bill Acceptance Test .....                          | A-11        |
| No. 9 DIP Switch Test .....                               | A-11        |
| <b>LED Diagnostics Codes.....</b>                         | <b>A-12</b> |
| Malfunction LED Error Codes .....                         | A-12        |
| Initialization LED Error Codes.....                       | A-14        |
| <b>LED Reject Codes .....</b>                             | <b>A-15</b> |
| <b>B GLOSSARY .....</b>                                   | <b>B-1</b>  |

# UBA-1x-SS & UBA-x4-SS/SU Series

## List of Figures

| LOF         |   | Page |
|-------------|---|------|
| Figure 1-1  | Universal Bill Acceptor (UBA-1x-SS & UBA-x4-SS/SU) .....                          | 1-1  |
| Figure 1-2  | Precautionary Symbols.....  | 1-2  |
| Figure 1-3  | Universal Bill Acceptor (UBA-1X-SS) Major Component Parts .....                   | 1-3  |
| Figure 1-4  | Universal Bill Acceptor (UBA-X4-SS/SU) Major Component Parts .....                | 1-4  |
| Figure 1-5  | UBA System Configuration.....   | 1-6  |
| Figure 1-6  | UBA Automatic Centering Feature .....   | 1-6  |
| Figure 1-7  | UBA Anti-Pullback Feature .....   | 1-6  |
| Figure 1-8  | UBA Dispute Resolving Window Feature .....  | 1-7  |
| Figure 1-9  | Bill Acceptor UBA-1x-SS Complete Unit Dimensions Diagram .....                    | 1-8  |
| Figure 1-10 | Bill Acceptor UBA-1x-SS Complete Unit Dimensions with UBA Faceplate Diagram ..... | 1-9  |
| Figure 1-11 | Bill Acceptor UBA-1x-SS Complete Unit Dimensions with ICB Diagram .....           | 1-10 |
| Figure 1-12 | Bill Acceptor UBA-x4-SS Complete Unit Dimensions Diagram .....                    | 1-11 |
| Figure 1-13 | Bill Acceptor UBA-x4-SU Complete Unit Dimensions Diagram .....                    | 1-12 |
| Figure 1-14 | Bill Acceptor Standard Cash Box Dimensions Diagram .....                          | 1-13 |
| Figure 1-15 | Bill Acceptor Large Cash Box Dimensions Diagram .....                             | 1-14 |
| Figure 2-1  | Front Panel Dip Switch Block .....  | 2-1  |
| Figure 2-2  | End Mounting Screw Hole Locations.....  | 2-1  |
| Figure 2-3  | Side Mounting Screw Hole Locations.....   | 2-1  |
| Figure 2-4  | Circuit Board Mounted Red LED .....   | 2-1  |
| Figure 2-5  | Plate Key Lock Dimensions & Location .....  | 2-2  |
| Figure 2-6  | Key Lock Rotation Requirement.....  | 2-2  |
| Figure 2-7  | Removing Acceptor Unit.....   | 2-7  |
| Figure 2-8  | Installing Optional Circuit Board .....   | 2-7  |
| Figure 2-9  | Optional Conversion Board External Interface Connection Structure ..              | 2-8  |
| Figure 2-10 | Optional cc-Talk Conversion Board External Interface Connection Structure ..      | 2-8  |
| Figure 2-11 | 5V DC CPU Board Bottom View.....  | 2-9  |
| Figure 2-12 | 3.3V DC CPU Board Bottom View.....  | 2-9  |
| Figure 2-13 | Removing the Cash Box .....   | 2-10 |
| Figure 2-14 | Retrieving Bills .....  | 2-10 |
| Figure 2-15 | Clearing an Entrance Banknote Jam .....   | 2-10 |
| Figure 2-17 | Opening UBA Centering Mechanism.....  | 2-10 |
| Figure 2-18 | UBA Cleaning Locations.....   | 2-11 |
| Figure 2-19 | JCM Waffletechnology Cleaning Card.....   | 2-11 |
| Figure 2-20 | Faceplate LED Lighting Control Circuit Schematic Diagram .....                    | 2-12 |
| Figure 2-21 | Optional Conversion Board Interface Circuit Schematic Diagram.....                | 2-12 |

# List of Figures

## Continued

Page

|             |   |      |
|-------------|---|------|
| Figure 2-22 | UBA-10/11/12-SS Bill Acceptor CPU Board Schematic Diagram ..... | 2-13 |
| Figure 2-23 | UBA-14-SS Bill Acceptor CPU Board Schematic Diagram .....       | 2-14 |
| Figure 2-24 | External Connector Interface Circuit.....                       | 2-15 |
| Figure 2-25 | Bill Acceptor Operational Flowchart (Part 1) .....              | 2-17 |
| Figure 2-26 | Bill Acceptor Operational Flowchart (Part 2) .....              | 2-18 |
| Figure 4-1  | Acceptor Unit Removal.....                                      | 4-1  |
| Figure 4-2  | UBA Unit Cash Box & USB Board Removal.....                      | 4-1  |
| Figure 4-3  | Side and Top Cover Removal .....                                | 4-2  |
| Figure 4-4  | Side Cover Installation Points.....                             | 4-2  |
| Figure 4-5  | Transport Cover Removal .....                                   | 4-2  |
| Figure 4-6  | Front Access Door Removal.....                                  | 4-3  |
| Figure 4-7  | TR Opening Lever Disassembly .....                              | 4-3  |
| Figure 4-8  | TR CPU Board Removal .....                                      | 4-3  |
| Figure 4-9  | Upper Sensor Board Removal.....                                 | 4-4  |
| Figure 4-10 | Lower Sensor Board Removal.....                                 | 4-4  |
| Figure 4-11 | Roller Guide Removal .....                                      | 4-4  |
| Figure 4-12 | Stacking Motor Removal .....                                    | 4-5  |
| Figure 4-13 | Stacking Clutch Shaft Removal .....                             | 4-5  |
| Figure 4-14 | Right Guide Mounting Screw Removals.....                        | 4-5  |
| Figure 4-15 | Last Left Side Guide Mounting Screw Removal .....               | 4-6  |
| Figure 4-16 | UBA Side Frame Removals.....                                    | 4-6  |
| Figure 4-17 | UBA Guide B Removal .....                                       | 4-6  |
| Figure 4-18 | Transport Guide B Removal .....                                 | 4-6  |
| Figure 4-19 | Transport Guide E Removal .....                                 | 4-7  |
| Figure 4-20 | Centering Home Sensor Board Removal .....                       | 4-7  |
| Figure 4-21 | Encoder Sensor Board Removal .....                              | 4-7  |
| Figure 4-22 | Anti-Pullback Sensor Board Removal .....                        | 4-7  |
| Figure 4-23 | Anti-Pullback Motor Unit Removal.....                           | 4-8  |
| Figure 4-24 | Transport Motor Unit Removal .....                              | 4-8  |
| Figure 4-25 | Entrance Sensor Board Removal .....                             | 4-9  |
| Figure 4-26 | Exit Sensor Board Removal .....                                 | 4-9  |
| Figure 4-27 | Centering Motor Unit Removal .....                              | 4-9  |
| Figure 4-28 | Timing Belts Removal.....                                       | 4-9  |
| Figure 4-29 | Mover Gear #1 & #2 Removal .....                                | 4-10 |
| Figure 4-30 | Pulley Shaft Removals .....                                     | 4-10 |
| Figure 4-31 | Mover Worm Gear Shaft Removal .....                             | 4-10 |
| Figure 4-32 | Transport Drive Shaft Removal .....                             | 4-10 |
| Figure 4-33 | Drive Belt Removal.....   | 4-11 |
| Figure 4-34 | Transport Guide D Solenoid Removal.....                         | 4-11 |

# List of Figures

## Continued

|  | Page |
|--|------|
| Figure 4-35 Cash Box Handle Removal .....  | 4-11 |
| Figure 4-36 ICB Module Removal.....  | 4-11 |
| Figure 4-37 Cash Box Sensor Removal .....  | 4-12 |
| Figure 4-38 Pusher Mechanism Unit Removal .....  | 4-12 |
| Figure 4-39 Pusher Mechanism Separation .....  | 4-12 |
| Figure 4-40 Cover Roller Removal .....   | 4-12 |
| Figure 4-41 Timing Belt Removal Access.....  | 4-13 |
| Figure 4-42 Timing Belt Removal .....  | 4-13 |
| Figure 5-1 Universal Bill Acceptor (UBA) Primary Components .....                                | 5-1  |
| Figure 5-2 UBA-10-SS Bill Acceptor System Wiring Diagram .....                                   | 5-3  |
| Figure 5-3 UBA-11/12-SS Bill Acceptor System Wiring Diagram .....                                | 5-5  |
| Figure 5-4 UBA-14-SS & UBA-24-SS/SU External Connector Interface Circuit<br>Wiring Diagram ..... | 5-7  |
| Figure 5-5 UBA-14/24 Optional Conversion Board Interface Circuit Wiring<br>Diagram .....         | 5-9  |
| Figure 6-1 Download USB Cable Requirement .....  | 6-1  |
| Figure 6-2 Required Download Workbench Tools .....   | 6-1  |
| Figure 6-3 UBA DIP Switch & Port Location .....  | 6-2  |
| Figure 6-4 Initial Setup Screen .....  | 6-2  |
| Figure 6-5 Customer Information Screen.....  | 6-2  |
| Figure 6-6 Destination Folder Screen .....   | 6-2  |
| Figure 6-7 Ready to Install Screen .....   | 6-3  |
| Figure 6-8 Software Installing Screen.....   | 6-3  |
| Figure 6-9 Installation Finished Screen .....  | 6-3  |
| Figure 6-10 Initial Program Installation Screen.....   | 6-3  |
| Figure 6-11 PC Browse Screen .....   | 6-4  |
| Figure 6-12 Installation Complete Screen.....  | 6-4  |
| Figure 6-13 Required Calibration Workbench Tools .....   | 6-4  |
| Figure 6-14 Opened UBA_ADJTOOL File Screen.....  | 6-5  |
| Figure 6-15 COM Port Selection Screen .....  | 6-5  |
| Figure 6-16 White Reference Test Screen .....  | 6-5  |
| Figure 6-17 Black Reference Test Screen.....   | 6-5  |
| Figure 6-18 White Test Paper Insertion Request.....  | 6-6  |
| Figure 6-19 Black Test Paper Insertion Request .....   | 6-6  |
| Figure 6-20 Set UV Reference Test Screen .....   | 6-6  |
| Figure 6-21 UV Test Paper Insertion Request.....   | 6-6  |
| Figure 6-22 Remove UV Reference Test Screen .....  | 6-6  |
| Figure 6-23 MAG HEAD Adjustment Dialog Screen .....  | 6-7  |
| Figure 6-24 MAG HEAD Adjustment Successful Screen .....  | 6-7  |

# List of Figures

## Continued

|  | Page |
|--|------|
| Figure 6-25 UBA-USB Tool Suite Opening Screen .....  | 6-8  |
| Figure 6-26 UBA-USB Driver Install Screen .....  | 6-8  |
| Figure 6-27 Re-Opened UBA-USB Tool Suite Screen .....  | 6-8  |
| Figure 6-28 UBA-USB Tool Suite Standard Screen .....   | 6-9  |
| Figure 6-29 UBA Downloader Program Screen.....   | 6-9  |
| Figure 6-30 UBA-USB Tool Suite ACCLoad Screen .....  | 6-9  |
| Figure 6-31 UBA-USB Tool Suite Sensor Adjustment Screen.....   | 6-9  |
| Figure 7-1 Entire UBA-10/11/12-SS & 14/24/25-SS/SU Units, Accessory & Optional Part Exploded Views ..... | 7-1  |
| Figure 7-2 UBA Transport Cover Assembly Exploded View (Part 1).....                                      | 7-3  |
| Figure 7-3 UBA Transport Unit Exploded View (Part 2).....  | 7-4  |
| Figure 7-4 UBA Transport Unit Exploded View (Part 3).....  | 7-5  |
| Figure 7-5 UBA Transport Unit Exploded View (Part4).....   | 7-6  |
| Figure 7-6 Frame Unit Exploded View .....  | 7-12 |
| Figure 7-7 UBA-SS Standard Cash Box Exploded View (Part 1) .....   | 7-14 |
| Figure 7-8 UBA-SS Large Cash Box Exploded View (Part 2).....   | 7-15 |
| Figure 7-9 UBA Cash Box Unit Pusher Mechanism Exploded View.....   | 7-16 |
| Figure 7-10 Face Unit Exploded View .....  | 7-22 |

# UBA-1x-SS & UBA-x4-SS/SU Series

## List of Tables

| <b>LOT</b> |   | <b>Page</b> |
|------------|---|-------------|
| Table 1-1  | Model Number Specifications .....   | 1-2         |
| Table 1-2  | UBA-1x Technical Specification .....  | 1-5         |
| Table 1-3  | UBA-1x Environmental Specification .....  | 1-5         |
| Table 1-4  | UBA-1x Electrical Specification .....   | 1-5         |
| Table 1-5  | UBA-1x Structural Specification .....   | 1-5         |
| Table 1-6  | Country Code Listings .....   | 1-15        |
| Table 2-1  | DIP Switch Settings .....   | 2-2         |
| Table 2-2  | UBA-10/11/12 Rear Panel Connector Pin Assignments .....                                   | 2-3         |
| Table 2-3  | UBA-14 Rear Panel Connector Pin Assignments .....   | 2-4         |
| Table 2-4  | UBA-24 Rear Panel Connector Pin Assignments .....   | 2-5         |
| Table 2-5  | UBA-1X & UBA-x4 Front Panel Bezel Connector Pin Assignments .....                         | 2-6         |
| Table 2-10 | Connector CN2 Pin Assignments .....   | 2-8         |
| Table 2-11 | Relay Connector Pin Assignments .....   | 2-8         |
| Table 2-12 | Optional cc-Talk Conversion Board Connector Pin Assignments .....                         | 2-9         |
| Table 2-13 | Optional USB Connector Pin Assignments .....  | 2-9         |
| Table 6-1  | Calibration Error Table .....   | 6-7         |
| Table 7-1  | Entire UBA-10/11/12-SS & UBA-14/24/25-SS/SU Unit, Accessories & Optional Parts List ..... | 7-2         |
| Table 7-2  | UBA Transport Unit Parts List .....   | 7-7         |
| Table 7-3  | Frame Unit Parts List .....   | 7-13        |
| Table 7-4  | UBA Cash Box Unit Parts List .....  | 7-18        |
| Table 7-5  | Face Unit Parts List .....  | 7-23        |
| Table 7-6  | Optional Unit Parts List .....  | 7-23        |
| Table A-1  | General Fault Conditions .....  | A-1         |
| Table A-2  | Adjustment Fault Conditions .....   | A-3         |
| Table A-3  | Communication Fault Conditions .....  | A-4         |
| Table A-4  | Transport Motor Speed Test Error Conditions .....   | A-5         |
| Table A-5  | Bill Stacker Test Error Conditions .....  | A-6         |
| Table A-6  | UBA Running Test Error Conditions .....   | A-6         |
| Table A-7  | Anti-pullback Mechanism Test Error Conditions .....                                       | A-8         |
| Table A-8  | Centering Mechanism Test Error Conditions .....   | A-8         |
| Table A-9  | Solenoid Sensor Test Error Conditions .....   | A-9         |
| Table A-10 | UBA General Sensor Test Settings .....  | A-10        |
| Table A-11 | UBA Bill Acceptance Test Error Conditions .....   | A-11        |
| Table A-12 | DIP Switch Test Steps .....   | A-11        |
| Table A-13 | Malfunction LED Error Codes .....   | A-12        |
| Table A-14 | ICB Initialization Errors .....   | A-14        |
| Table A-15 | LED Reject Codes .....  | A-15        |

THIS PAGE INTENTIONALLY LEFT BLANK

# UBA® Series

## Universal Bill Acceptor (UBA-1x-SS & UBA-x4-SS/SU)

### Section 1

#### 1 GENERAL INFORMATION

This section provides a general overview of the Universal Bill Acceptor Series (UBA-1x-SS & UBA-x4-SS/SU) pictured in Figure 1-1. This first section is designed to help you navigate through the manual with ease and provides the following information:

- Model/Type Number Specifications
- Precautions
- Component Names
- System Configuration
- Specifications
- Primary Features
- Complete Unit Dimensions
- Unit Dimensions with UBA Faceplate
- Unit Dimensions with ICB

- Standard Cash Box Dimensions
- Country Codes

In order to make operation of this device easier and make navigation within this manual simpler, the following illustrations were used within the text:

- **Safety Instructions**, which need to be observed in order to protect the operators and equipment, have been written in bold text and have been given the pictographs: 
- **Special Notes**, which effect the use of the Bill Acceptor, have been written in *italic* text and have been given the pictograph: 
- **Steps**, requiring the operator to perform specific actions are given sequential numbers (1., 2., 3., etc.)



UBA-1x-SS Series

UBA-x4-SU Series

Figure 1-1 Universal Bill Acceptor (UBA-1x-SS & UBA-x4-SS/SU)

## Model/Type Number Specifications

Table 1-1: Model Number Specifications

| Nº   | Model: <b>UBA - ** - S* - **0 - 00 - ***** - *** - **</b><br>Nº (1,2) (3) (4,5,6) (7,8) (9,10,11,12,13) (14)(15)  |  |  |  |  |
|------|---|--|--|--|--|
| (1)  | Sensor Configuration<br>1. Security-Stacker (SS)      2. Up-Stacker (SU)  |  |  |  |  |
| (2)  | CPU Board Type<br>0. 8Mbit Flash ROM<br>1. 8Mbit EPROM  | 2. 16Mbit Flash ROM<br>4. USB interface applicable |  |  |  |
| (3)  | Stacking Configuration<br><b>SS = Security Stackter (Downward vertical stacking [standard])</b><br><b>SU = Stack Upward (Upward vertical stacking)</b>  |  |  |  |  |
| (4)  | Cash Box Capacity<br>5 = 500 Note Capacity  | 9 = 900 Note Capacity                              |  |  |  |
| (5)  | Cash Box Type/Color<br>0 = Black Plastic<br>S = Steel (WBA Style Box)   |  |  |  |  |
| (6)  | Cash Box Handle Type/Color<br>0 = Blue Plastic (standard)<br>1 = Red Plastic  | J = Steel (WBA)<br>N = None (WBA)                  |  |  |  |
| (7)  | Transport Unit Body Color<br>0 = Black w/Blue Cover (standard)  |  |  |  |  |
| (8)  | Transport Unit Cover Color<br>0 = Blue (standard)   |  |  |  |  |
| (9)  | Faceplate*<br>0 = Without Faceplate (standard)<br>1 = With JCM Standard UBA Faceplate (85mm wide)<br>2 = With Blue/Blue LED<br>A = With Blue/Blue LED (2-line)  |  |  |  |  |
| (10) | Intelligent Cash Box (ICB Option)<br>0 = ICB not supported (no ICB Board or ICB Cash Box)<br>1 = ICB supported (with ICB Board & ICB Cash Box)<br>2 = ICB supported (with ICB Board & UBA Cash Box)   |  |  |  |  |
| (11) | External Interface Board (Optional)<br>0 = Standard (no external I/F Board)<br>1 = With 24V - 13.5V + Rs232C I/F Conversion Board<br>2 = With RS232C I/F Conversion Board<br>3 = With cc-Talk I/F Communications Board<br>4 = With 24 VDC/13.5 VDC & USB I/F Conversion Board |  |  |  |  |
| (12) | Input/Output signals<br>F = Photo-coupler Isolation<br>R = RS232C   |  |  |  |  |
| (13) | Harnessing (External)<br>0 = No Harness<br>1 = Standard Harness<br>2 = OEM Harness<br>F = 24VDC/13.5VDC Conversion Harness (w/Photo Coupler)<br>R = 24VDC/13.5VDC Conversion Harness (w/RS-232C)  |  |  |  |  |
| (14) | Accepted Country Code<br>ISO 3166-based 3-digit Alpha Code (See page 1-15).   |  |  |  |  |
| (15) | Interface†<br>03 = JCM ID-003 Serial Interface<br>24 = OEM Interface  | 28 = OEM Interface (USB)                           |  |  |  |

\*. Contact your JCM Sales Representative for information concerning Faceplates, the ICB and other options available.

†. Contact your JCM Sales Representative for information concerning other interface styles.

## Precautions





Figure 1-2 Precautionary Symbols

The Figure 1-2 symbols are defined as follows:

- (Type 1)** Do not insert a torn, folded, or wet Banknote, as this action may cause a Banknote jam inside the unit.
- (Type 2)** Do not expose the unit to water. The unit contains several precision electronic devices which can be damaged if water or any liquid is sprayed or spilled into the unit.
- (Type 3)** Do not install the unit into a dusty environment. Dust may affect and degrade the sensor's performance.



## User Cautions

- Be sure to turn the power off before plugging or unplugging connectors.
- Firmly close the Unit's Transport path before applying power.
- When closing the Unit, ensure all service door locks click into place. Make sure to open and close the Unit's Banknote path access ports gently, and take care that no dust or other foreign objects enter when opening the guide area.
- Do not allow inventory stock to endure high temperature, high humidity or a dusty environment.
- Do not throw the Unit or drop it to the ground. Improper handling may cause personal injury and/or damage to the equipment.
- When opening the Upper Guide, hold the guide up since it does not stay in the open position by itself.
- If the Bill Validator is dirty due to dust, foreign objects, or other such debris adhering to it, Banknote acceptance rate will degrade.

Use a soft, lint-free cloth and a mild non-abrasive soap and water solution to clean dust and debris from the Banknote's path.




**Under no circumstances allow the cloth to be wet enough to allow excess fluid to run into the device; internal Printed Circuit Boards may be damaged. Do not use any Alcohol, solvents or scouring agents which can attack the plastic surfaces of the device.**

A new JCM authorized Waffletechnology Cleaning Card is now available for quick cleaning of the UBA Unit. Refer to page 2-

## UBA-10/11/12 Component Names


Figure 1-3 illustrates the UBA-10/11/12 Primary Component Parts and their relative locations.



**Figure 1-3 Universal Bill Acceptor (UBA-1X-SS) Major Component Parts**

## UBA-14/24 Component Names

Figure 1-3 illustrates the UBA-14/24 Primary Component Parts and their relative locations.



**Figure 1-4** Universal Bill Acceptor (UBA-X4-SS/SU) Major Component Parts

## Specifications

### Technical Specifications

**Table 1-2: UBA-1x Technical Specification**

|                           |  |
|---------------------------|--|
| Acceptance rate:          | Refer to the specific Country's Banknote Specifications when considering the following Parameters:<br>98% or greater*<br>*Note: The following Banknotes types are excluded:<br>a) Banknotes with excessive or poor magnetism or unclear graphics<br>b) Double (dual) notes<br>c) Worn, dirty, wet, torn or excessively wrinkled Banknotes<br>d) Banknotes having folded corners or edges<br>e) Banknotes having the wrong cut dimensions or printing displacement<br>f) When security measures against counterfeiting are implemented, the software may not fulfill the specified acceptance rate level. |
| Banknote Types Accepted:  | Width: 2.44 – 3.35 in. (62 – 85mm), Length: 4.72 – 6.5 in. (120 – 165mm [up to 6.7 in. (170mm) when using a WBA Steel Cash Box])   |
| Insertion Direction:      | Refer to the specific Country's Banknote Specifications relative to the Banknote Types being used  |
| Processing Speed:         | Approximately 2 seconds (from Banknote insertion to Vend Signal output)<br>Approximately 5 seconds (from Banknote insertion to stacking completion )   |
| Diagnostic Indicators:    | Front Panel Faceplate LEDs   |
| Escrow:                   | 1 Banknote   |
| Anti-stringing Mechanism: | Pull-Back (PB) Unit (anti-pullback system – JCM Patented)  |
| Cash Box Capacity:        | 500 notes or more  |
| Interface:                | USB 2.0 Compatable (full speed transfer [120 bps])<br>ID-003 JCM Standard Serial Interface (UBA-10/11/12)<br>ID-024 OEM Interface<br>ID-028 JCM USB Serial Interface (UBA-14/24)<br><b>(Ask JCM for the proper communication specification for your Unit)</b><br>Contact JCM for other Interface requirements if required.   |

### Environmental Specifications

**Table 1-3: UBA-1x Environmental Specification**

|                              |                                     |
|------------------------------|-------------------------------------|
| Operating Temperature:       | 41°F to ~ 122°F (5°C to ~ +50°C)    |
| Storage Temperature:         | - 4°F to ~ 140°F (-20°C to ~ +60°C) |
| Relative Operating Humidity: | 30% to ~ 85% RH (non-condensed)     |
| Relative Storage Humidity:   | 30% to ~ 86% RH (non-condensed)     |
| Visible Light Sensitivity:   | Avoid Direct Sunlight Contact       |
| Installation:                | Indoors Only                        |

### Electrical Specifications

**Table 1-4: UBA-1x Electrical Specification**

|                      |   |
|----------------------|---|
| Supply Voltage:      | 12VDC ± 5%<br><b>(NOTE: Use a power supply with a 4.0A or more capability)</b><br>A 24VDC to12VDC conversion board option is available. |
| Current Consumption: | Standby = 300mA<br>Operation = 1.6A   |


### Structural Specifications

**Table 1-5: UBA-1x Structural Specification**

|                   |   |
|-------------------|---|
| Weight:           | Approximately 8.81 lbs (4.0kg)                                      |
| Mounting:         | Horizontal  |
| Outer Dimensions: | 11.73 in (298mm) High x 8.86 in (225mm) Deep x 4.49 in (114mm) Wide |

## System Configuration

Figure 1-5 illustrates a typical UBA system configuration.




**Figure 1-5** UBA System Configuration

## Primary Features

The UBA Series of Bill Validators contains the following primary features:


- **Automatic Centering**
  - The automatic centering mechanism allows the unit to read Banknotes ranging from 62 to 85mm in width without using special Banknote guides (See Figure 1-6). It helps to improve the overall acceptance rate.



**Figure 1-6** UBA Automatic Centering Feature

- **Proven Anti-pullback (anti-fishing) Technology**

- This JCM patented Anti-Pullback Mechanism provides powerful protection against Banknote stringing.
- The drum rotates every time a Banknote passes through the unit, and tangles around any foreign object attached to the Banknote, such as string and/or tape (See Figure 1-7).




**Figure 1-7** UBA Anti-Pullback Feature

- If any foreign object is detected, the UBA does not issue credit to the host controller.
  - **Changeable Photo-Coupler Isolation/RS-232C Communication**
    - Onboard electronics allows the use of TTL or RS-232C communication without requiring additional signal conversion boards.
-  *NOTE: See Figure 2-11 and Figure 2-12 in Section 2 of this Manual for Jumper Configuration combination settings.*

- **Plastic Cash Box**

- Durable and impact-resistant plastic construction assures secure cash handling.
- Equipped with dispute resolving windows to reveal the denominational value of last the last Banknote inserted (See Figure 1-8).



**Figure 1-8 UBA Dispute Resolving Window Feature**

- **ICB System (Optional)**

- This JCM patented Intelligent Cash Box (ICB) system is designed to increase the casino operators efficiency by reducing common errors prevalent in casino drop and count processes. In addition to time and cost savings, the ICB system provides an accumulated data analysis for accountability and profitability.

## Standard Unit Dimensions

Figure 1-9 illustrates the UBA-1x-SS standard unit dimensions.

NOTES:

! All dimensions shown are for reference purpose and are subject to manufacturing & assembly tolerances.

! All dimensions shown are in mm unless otherwise indicated.





Figure 1-9 Bill Acceptor UBA-1x-SS Complete Unit Dimensions Diagram

## UBA-1x Unit Dimensions with UBA Faceplate


Figure 1-10 illustrates the UBA-1x-SS complete unit dimensions with a UBA Faceplate.



**Figure 1-10** Bill Acceptor UBA-1x-SS Complete Unit Dimensions with UBA Faceplate Diagram

## UBA-1x Unit Dimensions with ICB


Figure 1-11 illustrates the UBA-1x-SS Complete Unit Dimensions with an Intelligent Cash Box (ICB).



**Figure 1-11 Bill Acceptor UBA-1x-SS Complete Unit Dimensions with ICB Diagram**

## UBA-x4-SS Unit Dimensions

Figure 1-12 illustrates the UBA-x4-SS Complete Unit Dimensions.




NOTE: All Dimensions are in Millimeters.

**Figure 1-12** Bill Acceptor UBA-x4-SS Complete Unit Dimensions Diagram

## UBA-x4-SU Unit Dimensions

Figure 1-13 illustrates the UBA-x4-SU Complete Unit Dimensions.




NOTE: All Dimensions are in Millimeters.

**Figure 1-13 Bill Acceptor UBA-x4-SU Complete Unit Dimensions Diagram**

## Standard Cash Box Dimensions


Figure 1-14 illustrates the Standard Cash Box dimensions.



**Figure 1-14 Bill Acceptor Standard Cash Box Dimensions Diagram**

## Large Cash Box Dimensions

Figure 1-15 illustrates the Large Cash Box dimensions.



**Figure 1-15** Bill Acceptor Large Cash Box Dimensions Diagram

**Country Codes****Table 1-6: Country Code Listings**

| <b>Country</b>            | <b>Country Code</b> |
|---------------------------|---------------------|
| Antilles                  | ANT                 |
| Argentine                 | ARG                 |
| Australia                 | AUS                 |
| Austria                   | AUT                 |
| Austria                   | AUT4                |
| Barbados                  | BRB                 |
| Belgium                   | BEL                 |
| Botswana                  | BWA                 |
| Brazil                    | BRA                 |
| Bulgaria                  | BGR                 |
| Canada                    | CAN                 |
| Canada                    | CAN                 |
| Chile                     | CHL                 |
| China                     | CHN                 |
| Colombia                  | COL                 |
| Costa Rica                | CRI                 |
| Croatia                   | HRV                 |
| Cyprus                    | CYP                 |
| Czech Republic            | CZE                 |
| Denmark                   | DNK                 |
| Estonia                   | ESTE                |
| Estonia                   | EST2                |
| European Union            | EUR                 |
| Finland                   | FIN                 |
| France                    | FRA                 |
| Germany                   | DEU                 |
| Germany                   | DEU1                |
| Germany                   | DEU2                |
| Germany/Sweden            | DEU/SWE             |
| Great Britain (England)   | GBR                 |
| Great Britain (England)   | GBR-B               |
| Great Britain/Gibraltar   | GBR/GBI             |
| Great Britain/Isle Of Man | GBR/MAN             |
| Greece                    | GRC                 |
| Greece                    | GRC-B               |
| Guatemala                 | MGT                 |
| Honduras                  | HND                 |
| Hong Kong                 | HKG                 |
| Hungary                   | HUN                 |

**Table 1-6: Country Code Listings (Continued)**

| <b>Country</b>      | <b>Country Code</b> |
|---------------------|---------------------|
| Iceland             | ISL                 |
| India               | IND                 |
| Israel              | ISR                 |
| Italy               | ITA                 |
| Italy               | ITA8                |
| Italy               | ITA9                |
| Japan               | JPN                 |
| Kazakhstan          | KAZ                 |
| Kazakhstan          | KAZ1                |
| Latvia              | LVA                 |
| Lithuania           | LTU                 |
| Malaysia            | MYS                 |
| Malaysia            | MYS1                |
| Malta               | MLT                 |
| Mauritius           | MUS                 |
| Mexico              | MEX                 |
| Moldova             | MDA                 |
| Morocco             | MAR                 |
| Namibia             | NAM                 |
| Netherlands         | NLD                 |
| Netherlands         | NLD-B               |
| New Zealand         | NZL                 |
| New Zealand         | NZL1                |
| New Zealand         | NZL-B               |
| North Ireland       | NIRL                |
| Norway              | NOR                 |
| Norway              | NOR1                |
| Peru                | PER                 |
| Peru                | PER1                |
| Philippines         | PHL                 |
| Philippines         | PHL1                |
| Poland              | POL                 |
| Poland              | POL1                |
| Poland              | POL1-B              |
| Portugal            | PRT                 |
| Qatar               | QAT                 |
| Republic Of Ireland | IRL                 |
| Republic Of Korea   | KOR                 |
| Republic Of Korea   | KOR-B               |
| Romania             | ROM                 |

**Table 1-6:** Country Code Listings (Continued)

| Country                    | Country Code |
|----------------------------|--------------|
| Russia                     | RUS          |
| Russia                     | RUS-B        |
| Saudi Arabia               | SAU          |
| Singapore                  | SGP          |
| Singapore                  | SGP-B        |
| Slovakia                   | SVK          |
| Slovenia                   | SVN          |
| South Africa               | ZAF          |
| Spain                      | ESP          |
| Sri Lanka                  | LKA          |
| Sweden                     | SWE          |
| Switzerland                | CHE          |
| Switzerland                | CHE3         |
| Switzerland                | CHE-B        |
| Taiwan (Republic Of China) | TWN          |
| Tanzania                   | TZA          |
| Thailand                   | THA          |
| Trinidad & Tobago          | TTO          |
| Ukraine                    | UKR          |
| Ukraine                    | UKR1         |
| United Arab Emirates       | ARE          |
| United States              | USA          |
| Uruguay                    | URY          |
| Uruguay                    | URY1         |
| Venezuela                  | VEN          |
| Venezuela                  | VEN1         |
| Venezuela                  | VEN2         |
| Venezuela                  | VEN-B        |

These Country Codes conform to the ISO 3166  
Country Code list definitions.

## Technical Contact Information

To obtain further Technical Information regarding the UBA Device, please contact the closest office to your location listed below:

### Americas & Oceania

#### JCM AMERICAN CORPORATION

Phone: +1-702-651-0000

Fax: +1-702-644-5512

925 Pilot Road, Las Vegas, NV 89119

E-mail: customerservice@jcmglobal.com

### Europe, Africa, Russia & Middle East

#### JCM EUROPE GMBH

Phone: +49-211-530-645-60

Fax: +49-211-530-645-85

Muendelheimer Weg 60

40472 Duesseldorf Germany

E-mail: support@jcm-germany.com

### UK & Ireland

#### JCM UNITED KINGDOM LTD.

Phone: +44-(0)870-770-2863

Fax: +44 (0) 190-837-7834

Unit B, Third Avenue

Denbigh West Business Park

Bletchley, Milton Keynes,

Buckinghamshire MK1 1EJ, UK

E-mail: info@jcm-uk.com

### Asia

#### JCM GOLD (HK) LTD.

Phone: +852-2429-7187

Fax: +852-2929-7003

Unit 1-7, 3/F., Favor Industrial Centre

2-6 Kin Hong Street, Kwai Chung,

N.T. Hong Kong

E-mail: cs@jcmgold.com.hk

#### JAPAN CASH MACHINE CO, LIMITED (HQ)

Phone: +81-6-6703-8400

Fax: +81-6-6707-0348

2-3-15, Nishiwaki, Hirano-ku, Osaka 547-0035 JAPAN

E-mail: Shohin@jcm-hq.co.jp

All of these Websites are available via:

<http://www.jcmglobal.com>

THIS PAGE INTENTIONALLY LEFT BLANK

# UBA® Series

## Universal Bill Acceptor (UBA-1x-SS & UBA-x4-SS/SU)

### Section 2

## 2 INSTALLATION/OPERATION

This section provides installation and operation instructions for the Universal Bill Acceptor Series (UBA). The information within contains the following features:

- Installation
- Lock Installation
- DIP Switch Configurations
- Connector Pin Assignments
- Jumper Configurations
- Retrieving Banknotes
- Clearing a Banknote Jam
- Cleaning/Preventive Maintenance
- Operational Flowchart
- Interface Circuit Schematic

### Installation

Perform the following steps to install the UBA unit:

1. Remove power from host machine.
2. Set UBA DIP Switches if required (See Figure 2-1). The initial setting is all switches OFF to enable all denominations.




Figure 2-1 Front Panel Dip Switch Block

3. Connect the proper interface harness from the host machine to the UBA.
4. Install the UBA into the host machine using Flat Head M4 mounting screws. There are four mounting holes located on the frame end and three located on each side of the frame (See Figure 2-2 & Figure 2-3).



*NOTE: The maximum length of M4 Flat Head Screws should be 4mm plus the thickness of the cabinet or mounting bracket. Example: If the UBA is mounted on a bracket that is 2mm thick, the M4 screws should be no more than 6mm in length.*





Figure 2-2 End Mounting Screw Hole Locations




Figure 2-3 Side Mounting Screw Hole Locations

5. Apply power to the machine and verify that the Circuit Board mounted Red Chip LED, located to the left of the DIP Switch Block, is illuminated (ON) (See Figure 2-4), and both the Red and Green frame mounted Front Panel Indicator LEDs are extinguished (OFF).




Figure 2-4 Circuit Board Mounted Red LED


- If the red chip LED is OFF, check connections and make sure power is applied.
  - If any of the indicator LEDs are ON, check error codes to fix the problem.
6. Check operation by inserting banknotes of each denomination to verify that the notes are accepted and properly credited by the host machine.

## Lock Installation

One or two security locks can be installed onto a UBA Cash Box. When installing a security lock, the following attachment accessories may be required:

1. Two key spacers
2. Plate lock keys and
3. A key cap attachment.

Dimensions of the Plate Key Lock is illustrated in Figure 2-5.




**Figure 2-5** Plate Key Lock Dimensions & Location

Choose a Lock that fits a standard 5/8" or 1-1/8" hole dimension format, because they are the only formats supported. Use a key spacer if required. When using only one lock, the remaining blank hole does not provide access to Cash Box contents. However, some regulatory authorities may require installation of a key cap.

 **NOTE:** When two locks are installed, they must rotate in the same direction as illustrated in Figure 2-6.

 **NOTE:** There are many lock designs, and key spacer washers may be required for some lock types. Locks vary greatly in price, security, keying policies, et cetera. The customer is responsible for selecting a lock with performance that fits the intended purpose. JCM does not test or endorse any specific brand of lock for its security characteristics.



**Figure 2-6** Key Lock Rotation Requirement

## DIP Switch Configurations

Table 2-1 lists the default DIP Switch configurations for the UBA Front panel DIP Switch Block.



**NOTE:** DIP Switch settings may vary based on software changes related to the specific country using the UBA. Please contact your local JCM Customer Representative for the latest setting information, or visit the JCM Website at [www.jcmglobal.com](http://www.jcmglobal.com).

**Table 2-1** DIP Switch Settings

| UBA Front Panel Switches               |                               |                              |
|--|-------------------------------|------------------------------|
|  | OFF                           | ON                           |
| Default Setting = ALL Switches are OFF |                               |                              |
| <b>Switch No.</b>                      | <b>Switch ON</b>              | <b>Switch OFF</b>            |
| 1                                      | TITO* barcode coupon disabled | TITO* barcode coupon enabled |
| 2                                      | \$1 Banknote disabled         | \$1 Banknote enabled         |
| 3                                      | \$5 Banknote disabled         | \$5 Banknote enabled         |
| 4                                      | \$10 Banknote disabled        | \$10 Banknote enabled        |
| 5                                      | \$20 Banknote disabled        | \$20 Banknote enabled        |
| 6                                      | \$50 Banknote disabled        | \$50 Banknote enabled        |
| 7                                      | \$100 Banknote disabled       | \$100 Banknote enabled       |
| 8                                      | TEST Mode                     | NORMAL Mode                  |

\*. TITO = Ticket In Ticket Out

## Connector Pin Assignments

Table 2-2 through Table 2-5 list the various UBA Connector Type Pin Assignments. Table 2-2 lists the UBA-10/11/12 Rear Panel Connector Pin Assignments, Table 2-3 lists the UBA-14 Rear Panel Connector Pin Assignments and Table 2-4 lists the UBA-24 Rear Panel Connector Pin Assignments.

**Table 2-2** UBA-10/11/12 Rear Panel Connector Pin Assignments

| UBA-10/11/12 Rear Panel Connector |                |                  |  |
|-----------------------------------|----------------|------------------|--|
| Pin No.                           | Signal Name*   | I/O <sup>†</sup> | Function   |
| 1                                 | +12V POWER     |                  | +12V DC power  |
| 2                                 | GROUND (Power) |                  | 0V DC Ground Plain   |
| 3                                 | M. RES         | In               | Bill Acceptor master reset signal line                     |
| 4                                 | PC/RS232C OUT  | Out              | Serial data signal output line from Acceptor to Controller |
| 5                                 | +12V I/F       |                  | +12V DC Interface Power                                    |
| 6                                 | PC/RS232C IN   | In               | Serial data signal input line from Controller to Acceptor  |
| 7                                 | GND I/F        |                  | Photo-coupler Zero (0) Volt DC Interface power             |
| 8                                 | (TTL1)         | (In)             | Reserved (TTL1) input                                      |
| 9                                 | (TTL1)         | (Out)            | Reserved (TTL1) output                                     |
| 10                                | (TTL2)         | (In)             | Reserved (TTL2) input                                      |
| 11                                | (TTL2)         | (Out)            | Reserved (TTL2) output                                     |
| 12                                | (TTL3)         | (In)             | Reserved (TTL3) input                                      |
| 13                                | GND            |                  | RS232C 0 Volt DC Interface power                           |
| 14                                | LED POWER      |                  | LED drive line - anode                                     |
| 15                                | (TTL4)         | (In)             | Reserved (TTL4) input                                      |
| 16                                | (TTL5)         | (In)             | Reserved (TTL5) input                                      |
| 17                                | (TTL3)         | (Out)            | Reserved (TTL3) output                                     |
| 18                                | LED- (TTL4)    | (Out)            | LED Drive Line - cathode (TTL4)                            |
| 19                                | (TTL5)         | (Out)            | Reserved (TTL5) output                                     |
| 20                                | (TTL6)         | (Out)            | Reserved (TTL6) output                                     |

\*. Signal name, I/O, and function without parenthesis are for ID-003 interface.

†. I/O (input/output) is the terminal viewed from Banknote Acceptor's side.



*NOTE: Photo-coupler and RS-232C signal level isolation can be jumper selected using jumpers located on the CPU board. The related jumper selections are described in "Jumper Configurations" on page 9 and page 10 of this Section.*

## Connector Pin Assignments (Continued 1)

Table 2-3 lists the UBA-14 Rear Panel Connector Pin Assignments.

**Table 2-3** UBA-14 Rear Panel Connector Pin Assignments

| UBA-14 Rear Panel Connector |                |        |  |
|-----------------------------|----------------|--------|--|
| Pin No.                     | Signal Name *  | I/O†   | Function   |
| 1                           | +12V POWER     |        | +12V DC power  |
| 2                           | GROUND (Power) |        | 0V DC Ground Plain   |
| 3                           | M. RES         | In     | Bill Acceptor's master reset signal line                   |
| 4                           | PC/RS232C OUT  | (Out)  | Serial data signal output line from Acceptor to Controller |
| 5                           | +12V I/F       |        | +12V DC Interface Power                                    |
| 6                           | PC/RS232C IN   | (In)   | Serial data signal input line from Controller to Acceptor  |
| 7                           | GND I/F        |        | Photo-coupler Zero (0) Volt DC Interface power             |
| 8                           | Vbus           |        | USB Communication Vbus signal line: DC +5V                 |
| 9                           | -DATA          | IN/OUT | USB Communication input/output signal line                 |
| 10                          | +DATA          | IN/OUT | USB Communication input/output signal line                 |
| 11                          | (TTL1)         | (Out)  | Reserved (TTL1) output                                     |
| 12                          | GND USB        |        | USB Communication Ground: DC 0V                            |
| 13                          | (GND I/F)      |        | (Interface power: RS232C DC0V)                             |
| 14                          | LED POWER      |        | LED drive line - anode                                     |
| 15                          | (TTL1)         | (In)   | Reserved (TTL1) input                                      |
| 16                          | (TTL2)         | (In)   | Reserved (TTL2) input                                      |
| 17                          | (TTL3)         | (In)   | Reserved (TTL3) output                                     |
| 18                          | LED- (TTL2)    | (Out)  | LED Drive Line - cathode (TTL2)                            |
| 19                          | (TTL3)         | (Out)  | Reserved (TTL3) output                                     |
| 20                          | NC             |        | No Connection  |

\*. Signal name, I/O, and function with parenthesis are for photo-coupler isolation and RS-232C only.

†. I/O (input/output) is the terminal viewed from Bill Acceptor's side.

## Connector Pin Assignments (Continued 2)

Table 2-4 lists the UBA-24 Rear Panel Connector Pin Assignments.

**Table 2-4** UBA-24 Rear Panel Connector Pin Assignments

| UBA-24 Rear Panel Connector |                  |                  |  |
|-----------------------------|------------------|------------------|--|
| Pin No.                     | Signal Name *    | I/O <sup>†</sup> | Function                                   |
| 1                           | +12V POWER       |                  | +12V DC power                              |
| 2                           | GROUND (Power)   |                  | 0V DC Ground Plain                         |
| 3                           | M. RES           | In               | Bill Acceptor's master reset signal line   |
| 4                           | NC               |                  | Reserved                                   |
| 5                           | +12V I/F         |                  | +12V DC Interface Power                    |
| 6                           | NC               |                  | Reserved                                   |
| 7                           | NC               |                  | Reserved                                   |
| 8                           | Vbus             |                  | USB Communication Vbus signal line: DC +5V |
| 9                           | -DATA            | IN/OUT           | USB Communication input/output signal line |
| 10                          | +DATA            | IN/OUT           | USB Communication input/output signal line |
| 11                          | NC               |                  | Reserved                                   |
| 12                          | GND USB          |                  | USB Communication Ground: DC 0V            |
| 13                          | NC <sup>‡</sup>  |                  | Reserved                                   |
| 14                          | LED POWER        |                  | LED drive line - anode                     |
| 15                          | NC               |                  | Reserved                                   |
| 16                          | NC               |                  | Reserved                                   |
| 17                          | NC               |                  | Reserved                                   |
| 18                          | LED- (TTL2)      |                  | LED Drive Line - cathode                   |
| 19                          | NC               |                  | Reserved                                   |
| 20                          | NC <sup>**</sup> |                  | No Connection                              |

\*. Signal name, I/O, and function with parenthesis are for photo-coupler isolation and RS-232C only.


†. I/O (input/output) is the terminal viewed from Bill Acceptor's side.

‡. Short to Pin 20 for use as an SU Unit.

\*\*. Short to Pin 13 for use as an SU Unit.






**Figure 2-9** Optional Conversion Board External Interface Connection Structure**Table 2-10** Connector CN2 Pin Assignments

| Connector CN2 |   |
|---------------|---|
|               | Header: 53103-0430 (Japan Molex)<br>Contact Type: 50083-8014 (Japan Molex)<br>Housing: 51030-0430 (Japan Molex) |
| Pin No.       | Signal Name   |
| 1             | M Reset   |
| 2             | T <sub>XD</sub>   |
| 3             | R <sub>XD</sub>   |
| 4             | Interface Ground  |


**Table 2-11** Relay Connector Pin Assignments

| Relay Connector |  |
|-----------------|--|
|                 | Header: 51029-0310 (Japan Molex)<br>Contact Type: 50087-8014 (Japan Molex)<br>or 70021-00041 (USA Molex)<br>Housing: 51030-0330 (Japan Molex)<br>Contact Type: 51030-0430 (Japan Molex)<br>Recommended Wire: UL1007 AWG#24 to 26 |
| Pin No.         | Signal Name  |
| 1               | 24 VDC   |
| 2               | 12 VDC   |
| 3               | Interface Ground   |

Figure 2-10 illustrates the External Interface Connection Structure for an Optional cc-Talk Conversion Board.


**Figure 2-10** Optional cc-Talk Conversion Board External Interface Connection Structure






**Figure 2-13** Removing the Cash Box

2. When a lock is installed, use the appropriate key to unlock the Cash Box. For details concerning locks, refer to “Lock Installation” on page 2 of this section.
3. Open the Cash Box door and retrieve the Banknotes as illustrated in Figure 2-14.




**Figure 2-14** Retrieving Bills



**Figure 2-15** Clearing an Entrance Banknote Jam

When a Banknote is jammed near the Cash Box entrance:

1. Pull on the box’s handle to remove the Cash Box from frame, then
2. Remove the jammed Banknote (See Figure 2-16).



**Figure 2-16** Clearing Cash Box Entrance Banknote Jams

## Clearing a Banknote Jam


When a Banknote is jammed near the Bill Acceptor's entrance:

1. Pull the tab located on the top of the Acceptor to open the units cover and
2. Remove the jammed Banknote (See Figure 2-15).



**Figure 2-17** Opening UBA Centering Mechanism

**!** **Do not use alcohol, thinner or citrus based products for cleaning any surfaces.**



**Figure 2-18 UBA Cleaning Locations**

If a Bill jam occurs when the centering mechanism is closed, the cover will not open. To un-jam the unit, recycle power and allow the unit to reset.



**NOTE:** If recycling the power fails to clear the jam, use a 2.5 mm Hex Nut Driver (JCM part # 501-000131) to rotate the mover guide shaft, then open the Top Cover to remove jam (See Figure 2-17).


## Cleaning/Preventive Maintenance

To clean the lenses, use a lint-free cloth and a mild non-abrasive detergent such as liquid dish soap mixed with water. It is important to keep the bill path, rollers, and belts clean. Use a soft lint-free cloth or a cotton swab to wipe dirt and stains from the surfaces of the magnetic and optical sensors, rollers and belts. The sensor lenses are transparent, and made of a polymer material. Handle them with care. Repeat the cleaning process as needed until the Transport path is free of contaminants (See Figure 2-18).

## Available Cleaning Card

A second generation JCM Waffletechnology Bill Validator Cleaning Card is now available (JCM Part No. 501-000180R, Manufacturer's Part No. KWJCM-B2B15M). The cleaning card is designed to be used as a supplemental part of a Preventive Maintenance program to help in reducing dirt and paper dust build-up within a unit. This will optimize performance between regular Preventive Maintenance intervals. This is the only cleaning

card authorized for use on the UBA Gaming Validator (See Figure 2-19).



**Figure 2-19 JCM Waffletechnology Cleaning Card**

### CARD FEATURES

- A unique Waffletechnology design that hugs all surfaces to insure complete surface cleaning
- Specially designed scrubber patterns insure that belts and O-ring rollers are cleaned and lubricated to prevent them from drying out.

### DIRECTIONS FOR USE

1. Remove cleaning card from pouch and insert it into the Bill Validator.
2. The cleaning card will be accepted and then automatically feed in-and-out several times.
3. Insert and HOLD cleaning card while the Validator pulls on it to ensure proper belt cleaning.
4. Dispose of used card in an environmentally safe manner.


For more information and a list of Authorized Waffletechnology Distributors visit:

<http://www.jcmwaffletechnology.com>.

## UBA 10/11/12/14 & 24 Related Schematics

### UBA Faceplate LED Lighting Control Circuit Schematic


Figure 2-20 illustrates the Standard Faceplate LED Lighting Control Circuit Schematic Diagram.



**Figure 2-20** Faceplate LED Lighting Control Circuit Schematic Diagram

### UBA Optional Conversion Board Interface Circuit Schematic

Figure 2-21 illustrates the Optional Conversion Board Interface Circuit Schematic Diagram.



**Figure 2-21** Optional Conversion Board Interface Circuit Schematic Diagram

## UBA 10/11/12-SS Standard Interface Circuit Schematic

Figure 2-22 illustrates the CPU Board UBA-10/11/12-SS Schematic Diagram.





Figure 2-22 UBA-10/11/12-SS Bill Acceptor CPU Board Schematic Diagram

## UBA-14-SS Interface Circuit Schematic

Figure 2-23 illustrates the CPU Board UBA-14-SS Schematic Diagram.



**Figure 2-23 UBA-14-SS Bill Acceptor CPU Board Schematic Diagram**

## External Input/Output Connector Circuit Schematic

Figure 2-24 illustrates the External Connector Interface Circuit Schematic Diagram.





Figure 2-24 External Connector Interface Circuit

THIS PAGE INTENTIONALLY LEFT BLANK

## Operational Flowcharts


Figure 2-20 depicts part one of a typical Banknote acceptance flow process.



**Figure 2-25 Bill Acceptor Operational Flowchart (Part 1)**

## Operational Flowchart (Continued)

Figure 2-26 depicts part two of a typical Banknote acceptance flow process.



\*1: Faulty bill validation is suspect when a bill is automatically reinserted several times for re-evaluation. The Bill Validator will attempt to examine a bill three (3) times before rejecting the bill.

\*2: When an abnormal signal condition occurs, remove the bill causing the malfunction and re apply power to the UBA or send a reset command to the Bill Acceptor.

\*3: When a Stack Full signal occurs, remove the bills from the Cash Box and re-install it into its fully seated position. The UBA will then automatically reinitialize itself.

**Figure 2-26** Bill Acceptor Operational Flowchart (Part 2)

# **UBA® Series**

## **Universal Bill Acceptor (UBA-1x-SS & UBA-x4-SS/SU)**

### **3 COMMUNICATIONS**

**This section was intentionally left out due to a Non-Disclosure Agreement requirement.**

**If this information is required, please contact the closest office location listed below:**

#### **Americas & Oceania**

##### **JCM AMERICAN CORPORATION**

Phone: +1-702-651-0000

Fax: +1-702-644-5512

925 Pilot Road, Las Vegas, NV 89119

E-mail: customerservice@jcmglobal.com

#### **Europe, Africa, Russia & Middle East**

##### **JCM EUROPE GMBH**

Phone: +49-211-530-645-60

Fax: +49-211-530-645-85

Muendelheimer Weg 60

40472 Duesseldorf Germany

E-mail: support@jcm-germany.com

#### **UK & Ireland**

##### **JCM UNITED KINGDOM LTD.**

Phone: +44-(0)870-770-2863

Fax: +44 (0) 190-837-7834

Unit B, Third Avenue

Denbigh West Business Park

Bletchley, Milton Keynes,

Buckinghamshire MK1 1EJ, UK

E-mail: info@jcm-uk.com

#### **Asia**

##### **JCM GOLD (HK) LTD.**

Phone: +852-2429-7187

Fax: +852-2929-7003

Unit 1-7, 3/F., Favor Industrial Centre

2-6 Kin Hong Street, Kwai Chung,

N.T. Hong Kong

E-mail: cs@jcmgold.com.hk

##### **JAPAN CASH MACHINE Co, LIMITED (HQ)**

Phone: +81-6-6703-8400

Fax: +81-6-6707-0348

2-3-15, Nishiwaki, Hirano-ku, Osaka 547-0035

JAPAN

E-mail: Shohin@jcm-hq.co.jp

All of these Websites are available via:

<http://www.jcmglobal.com>

THIS PAGE INTENTIONALLY LEFT BLANK

# UBA® Series

## Universal Bill Acceptor (UBA-1x-SS & UBA-x4-SS/SU)

### Section 4

#### 4 DISASSEMBLY/REASSEMBLY

This section provides disassembly and reassembly instructions for the Universal Bill Acceptor Series (UBA). This section contains the following information:

- Tool Requirements
- Primary Unit Disassembly
- Acceptor Unit Disassembly
- Circuit Board Removal
- Cash Box Handle and ICB Box Disassembly
- Transport Guides A, B, C, D, & E Disassembly
- Sensor Board Disassembly
- Transport Unit Motors Disassembly
- Transport C Timing Belt Disassembly
- Final Timing Belt Disassembly

#### Tool Requirements

The following tools will be required to perform disassembly and reassembly:

- #1 & #2 Phillips Screwdriver
- 2.5mm Hex Head Driver
- Set of Jewelers Phillips Screw Drivers
- E-Clip (E-Ring) Pliers
- Needle Nose Pliers
- Tweezers

#### Primary Unit Disassembly

The following instructions are provided to perform an initial disassembly of the Universal Bill Acceptor's primary parts.

1. Press down on the front latch and slide the UBA Acceptor assembly forward (See Figure 4-1).
2. Pull on the Cash Box handle and remove the Cash Box from the frame (See Figure 4-2 a).
3. When an optional 24V/USB Circuit Board is installed, remove the optional printed circuit board from the frame housing (See Figure 4-2 b).



*NOTE: Applicable screw size is 2.6x8 P.  
The tightening torque necessary is 56.89  
psi (4.0kgf/cm<sup>2</sup>).*




Figure 4-1 Acceptor Unit Removal





Figure 4-2 UBA Unit Cash Box & USB Board Removal

#### Acceptor Unit Disassembly

##### Side and Top Cover Removal

Perform the following steps to remove the UBA Acceptor side and top covers:

- Pull the release lever located on top of the Unit and fully open the Transport (TR) Section of the Acceptor's Cover in the direction of the large arrow shown in Figure 4-3 a.




**Figure 4-3 Side and Top Cover Removal**




**WARNING: Hold the Upper Guide open while removing the right and left Transport (TR) covers, because it does not stay in the upright position by itself. Improper handling may result in personal injury and/or damage to the equipment.**

- Fully open the front access door (See Figure 4-3 b).
- Lift and hold points ① and ② open on each TR Side Cover (See Figure 4-3 C1 & C2 and Figure 4-4 C1 & C2).



**Figure 4-4 Side Cover Installation Points**

- Slide each Cover in the direction indicated by the small arrows shown in Figure 4-3 C1 & C2 to remove each side cover.
- To remove the Transport Cover, release six (6) Tabs; three located on each side of the Transport Cover using a Flathead Screwdriver (See Figure 4-5).



**Figure 4-5 Transport Cover Removal**


- Remove the Transport Cover upward by lifting up the Front Cover.
- To re-attach the Side Covers to the Unit, place them in their proper position on each side of the Unit.
- Hold points ③, ④ and ⑤ on each Side Cover, (See Figure 4-3) and slide them in the reverse arrow direction as previously shown in Figure 4-4.

### Front Access Door Removal

Perform the following steps to remove the UBA Front Access Door:

- Turn the Acceptor Unit upside down.
- Remove the screw located on the side of the Front Access Door to release the Front Grounding (FG) Harness (See Figure 4-6 a).
- Fully open the Front Access Door and release the Acceptor Latch Spring Lock (See exploded view inset in Figure 4-6 b).
- Unscrew two screws located on the shaft and slightly widen the UBA Transport Unit in the directions of the small arrows shown in Figure 4-6 b, and remove the front access door from the Transport Unit in the large arrow direction (See Figure 4-6 c).

**NOTE: When re-assembling the Front Door, tighten the two (2) screws located on the shaft to a torque of 42.67 psi (3.0kgf/cm<sup>2</sup>).**




**Figure 4-6** Front Access Door Removal

### Opening Lever Disassembly

Perform the following steps to disassemble the UBA Acceptor's Transport Opening Lever:

1. Remove the Transport Cover (See "Side and Top Cover Removal" on page 4-1).
2. Remove the E-Clip located on the shaft end, and pull the Opener Latch Shaft out of the assembly (See Figure 4-7 a).



**Figure 4-7** TR Opening Lever Disassembly

3. Lift Transport Guide (TR) D, then remove the Opening Lever, the left and right Opening Lever Latches, and their related Opening Lever Springs.

**Caution: Make sure not to lose the small Latch Springs located beneath the left and right Opening Lever Latches!**

4. On re-assembly, the Opening Lever Spring (See Figure 4-7 b) needs to have its hook-end reformed as a half-round.


**NOTE:** *The Opening Latch Springs need to be replaced onto the Transport Guide D Latch Bosses with tweezers once the shaft has been re-inserted into the assembly!*

### Circuit Board Removal

#### CPU BOARD REMOVAL

Perform the following steps to remove the UBA CPU Board:

1. Turn the Acceptor Unit upside down.
2. Remove the ICB board from the top of the CPU Board (See Figure 4-8 a).
3. Lift up the Push Rivet located on the left side with a Flathead Screwdriver and remove the Wire Holder (See Figure 4-8 b).
4. Disconnect the three (3) sets of three (3) Harness connectors from CPU board (9 connectors total) (See Figure 4-8 c1, c2 & c3).
5. Unlock Transport Guide A, and pull the CPU Board forward, but not completely out of the assembly (See Figure 4-8 d).
6. Before pulling the CPU Board completely out of the assembly, disconnect the remaining two (2) Harness connectors located on the bottom side of the CPU Board assembly (See Figure 4-8 e).




**Figure 4-8** TR CPU Board Removal

**Caution:** When reinstalling the ICB Board onto the CPU Board, check that the PLUG and SOCKET Numbers agree to ensure a correct Harness plug reconnection.

#### UPPER SENSOR BOARD REMOVAL

Perform the following steps to remove the UBA Upper Sensor Board:

1. Remove the Transport Cover (See “Side and Top Cover Removal” on page 4-1)
2. Remove the four (4) circuit board mounting screws (See Figure 4-9) and disconnect the three (3) board Harness connectors.
3. Remove the Upper Sensor Board from the assembly.




**Figure 4-9** Upper Sensor Board Removal

#### LOWER SENSOR BOARD REMOVAL

Perform the following steps to remove the UBA Lower Sensor Board:

**NOTE:** The CPU Board must be removed first to gain access to the Lower Sensor Board (See “CPU Board Removal” on page 4-3).

1. Remove the Right Side Cover (See “Side and Top Cover Removal” on page 4-1)
2. Disconnect the three (3) Harness connectors from the Lower Sensor Board (See the Figure 4-10 exploded inset).
3. Remove the three (3) circuit board mounting screws, lift the Lower Sensor Board up and slide it out of the side of the assembly as illustrated in Figure 4-10.




**Figure 4-10** Lower Sensor Board Removal

#### Transport Guides A, B, C, D, & E Disassembly

##### TRANSPORT GUIDE A DISASSEMBLY


Perform the following steps to remove the UBA Transport Guide A assembly:

1. Remove the single screw retaining the Roller Guide Cap, and twist the Cap down and clockwise in the arrow direction shown in Figure 4-11 (a) step ①, then remove it up and off the assembly.



**Figure 4-11** Roller Guide Removal

2. Remove the E-Clip retaining the small torque transfer gear (See Figure 4-11 b & c1), then remove both the small and large gears from the assembly (See Figure 4-11 c1 & c2).
3. Using a finger, pull back on the spring loaded Roller Guide Home Lever (See Figure 4-11 d1 step ②) and pull the Roller Guide up and out of the assembly (See Figure 4-11 d2 step ③).
4. Turn the UBA Acceptor Unit upside-down.
5. Remove the single Encoder Sensor Board mounting screw and remove the Circuit Board from the assembly (See Figure 4-12 a).
- NOTE: When reassembling the Unit, align the dents located on the Stacking Gear Motor as shown in Figure 4-12 b1 step ①.***
6. Remove the two (2) Motor Mount Screws from the right side of the Unit (See Figure 4-12 b2).
7. Remove Stacking Motor from the right side of the Unit in the direction of the large down pointing arrow shown in Figure 4-12.



**Figure 4-12 Stacking Motor Removal**


8. Align the gear of the Clutch Spring Stopper as shown in step ② c1, then remove E-Clip (c2) and screw (c3) retaining the two gears, and lift them up and out of the assembly.

***NOTE: When remounting the Stacking Motor, be sure to rotate the dents on the Motor in the direction shown in Figure 4-12 before re-inserting it.***




***NOTE: The Stacking Motor Gear and the Clutch Spring Stopper must be realigned as shown in Figure 4-12 before remounting the Stacking Motor!***

9. Turn the UBA Acceptor Unit upside-down again.
10. Remove the Stacking Clutch Shaft retaining E-clip and Bushing (See Figure 4-13 a), then pull the assembly downward and out of the Unit in the direction of the large down pointing arrow shown in Figure 4-13.




**Figure 4-13 Stacking Clutch Shaft Removal**

11. Turn the UBA Acceptor Unit upside-down a third time as shown in Figure 4-14.




**Figure 4-14 Right Guide Mounting Screw Removals**

12. Use Needle-nose Pliers to disconnect the Encoder Sensor Board Harness Connector Plug from the internal Circuit Board through the frame access hole as shown in the exploded view inset in Figure 4-14 a.
13. Remove the Final Stacker Gear E-Clip and remove the Gear (See Figure 4-14 b).
14. Turn the UBA Acceptor Unit upside-down a fourth time.
15. Remove the four (4) right side Frame Mounting Screws indicated in Figure 4-14 c.
16. Remove the two (2) Transport Gear Cover retaining screws (See Figure 4-15 a), and remove the Transport Gear Cover from the Acceptor Unit assembly.



**Figure 4-15 Last Left Side Guide Mounting Screw Removal**

17. Remove the last remaining left side Guide Mounting Screw (See Figure 4-15 b).
18. Pull the Transport Opening Lever to open Transport Guide D. The Unit will separate into three pieces consisting of Transport Guide A, Transport Guides B & C, and Transport Guides D & E respectively (See Figure 4-16).




**Figure 4-16 UBA Side Frame Removals**

### Transport Guides B & C Disassembly


Perform the following steps to disassemble UBA Transport Guide B from Guide C:

1. Remove the Final Transport Gear E-Clip and remove the Final Transport Gear and a Parallel Pin located below it (See Figure 4-17 a).
2. Remove the 3rd Transport Gear as illustrated in Figure 4-17 b.



**Figure 4-17 UBA Guide B Removal**

3. Remove the Lower Sensor Board as previously described in the section discussing “Lower Sensor Board Removal” on page 4-4 of this Section.
4. Remove the mounting screw securing Grounding Plate #2 (See Figure 4-18 a) and the three (3) Guide B mounting screws to separate Transport Guide B from guide Section C (See Figure 4-18 b).




**Figure 4-18 Transport Guide B Removal**

### Transport Guides D & E Disassembly

Perform the following steps to disassemble UBA Transport Guide D from Guide E:

1. Remove the Tunnel Shaft E-Clip and pull the Tunnel Shaft out of the assembly in the direction shown by the large arrow in Figure 4-19a.



**Figure 4-19 Transport Guide E Removal**


2. Remove the two Fulcrum Pins (See Figure 4-19 b) and separate Transport Guide E away from Transport Guide D.

## Sensor Board Disassembly

### Home Centering Sensor Board Disassembly

Perform the following steps to remove the UBA Home Centering Sensor Board:

1. The Centering Home Sensor Board is attached to Transport Guide A. Remove the single Home Centering Sensor Board mounting screw, and lift the small circuit board up and off the assembly (See Figure 4-20).




**Figure 4-20 Centering Home Sensor Board Removal**

### Encoder Sensor Board Disassembly

Perform the following steps to remove the UBA Encoder Sensor Board:

1. The Encoder Sensor Board is attached to Transport Guide B. Remove the single Encoder Sensor Board mounting screw and lift the small circuit board up and off the assembly (See Figure 4-21).




**Figure 4-21 Encoder Sensor Board Removal**

## Anti-Pullback Home Sensor Board Disassembly

Perform the following steps to remove the UBA Anti-Pullback Home Sensor Board:

1. The Anti-Pullback Home Sensor Board is attached to Transport Guide B. Remove the Anti-Pullback Lever Spring from the Roller Guide Homing Lever as shown in Figure 4-22a.



**Figure 4-22** Anti-Pullback Sensor Board Removal


2. Remove the Roller Guide Homing Lever E-Clip (See Figure 4-22 b), and then remove the Anti-Pullback Home Sensor Board mounting screw.
3. Lift the circuit board up and off of the assembly (See Figure 4-22 c).

## Transport Unit Motors Disassembly

### Anti-Pullback Drive Motor Unit Disassembly

Perform the following steps to disassemble the UBA Anti-Pullback Motor Unit:

1. Remove the two (2) Anti-Pullback Motor Bar mounting screws (See Figure 4-23 c) and lift the Motor Bar assembly up and out of Transport Guide B.
2. Remove the 2nd Roller Gear retainer E-Clip and drop the 2nd Roller Gear down and out of the assembly (See Figure 4-23 b).
3. Remove the two (2) Anti-Pullback Motor Unit mounting screws and slide the Motor Unit back and out of the Motor Bar assembly (See Figure 4-23 a).




**Figure 4-23** Anti-Pullback Motor Unit Removal

**NOTE:** When re-assembling the Anti-Pullback Motor Bar onto the Anti-Pullback Motor Unit, fasten the mounting screws so that the 2nd Gear Roller and the Anti-Pullback Motor Assembly gears do not bind tightly against one other (See Figure 4-23 ①).

### Transport Motor Disassembly

Perform the following steps to disassemble the UBA Transport Motor Unit:

1. Pull the Transport Gear Pin up and out of the Transport Guide B Assembly (See Figure 4-24 a).
2. Lift the 2nd Transport Gear up and off the assembly as shown in Figure 4-24b.



**Figure 4-24** Transport Motor Unit Removal


3. Remove the two (2) Motor Mount Screws from Transport Guide B (See Figure 4-24 c).
4. Carefully drop the Transport Motor down in the direction of the large down pointing arrow shown in Figure 4-24d.

 **NOTE:** When re-mounting the Transport Motor, ensure that the Motor dents are aligned in the direction shown in the Figure 4-24 ① exploded view circle inset.

#### ENTRANCE SENSOR BOARD REMOVAL

Perform the following steps to remove the UBA Entrance Sensor Board:

1. Pull Guide Plate #1 out of the assembly in the direction indicated by the arrow shown in Figure 4-25a.




**Figure 4-25** Entrance Sensor Board Removal

2. Remove the single Entrance Sensor Board mounting screw (See Figure 4-25 b), disconnect Circuit Board Harness Connector Plug (See Figure 4-25 c), and remove Entrance Sensor Board from the assembly.

#### EXIT SENSOR BOARD DISASSEMBLY

Perform the following steps to remove the UBA Exit Sensor Board:

1. Disconnect the Exit Sensor Board Harness Connector Plug from Transport Guide C (See Figure 4-26 a).
2. Remove the Rear Sensor Guide assembly forward and then upward out of the Transport Guide C Assembly (See Figure 4-26 b).
3. Remove the single Exit Sensor Board mounting screw (See Figure 4-26 c), and lift the Exit Sensor Board off the assembly.




**Figure 4-26** Exit Sensor Board Removal

#### Centering Motor Unit Disassembly

Perform the following steps to disassemble the UBA Centering Motor Unit:

1. Remove the two (2) Centering Motor Unit mounting screws, then carefully lift the Centering Motor Unit up and off the assembly after disconnecting its Harness plug (See Figure 4-27).



**Figure 4-27** Centering Motor Unit Removal


#### Transport C Timing Belt Disassembly

##### Transport C Timing Belt Removal

Perform the following steps to remove the UBA Transport C Timing Belts:


1. Remove the four (4) Lower Sensor Spacer mounting screws out of Transport Guide C as shown in Figure 4-28.

- Remove Lower Sensor Spacer upward and slide it sideways out of Transport Guide C in the direction of the large arrow shown in Figure 4-29.



**Figure 4-28** Timing Belts Removal

- Rotate the 2nd Mover Gear in the direction indicated by the arrow shown in the Figure 4-29 exploded view inset.
- Remove Mover Guide Assemblies #1 and #2 out of each side of Transport Guide C (See Figure 4-29).




**Figure 4-29** Mover Gear #1 & #2 Removal




**Caution: When re-inserting Mover Guides #1 and #2, ensure that they have an identical sized spacing width (A=B) when being simultaneously reinstalled inside Transport Guide C (See Figure 4-29 ①).**

- Push Pulley Shaft #2 out of the assembly in the direction indicated by the arrow shown in Figure 4-30a.
- Remove the Mover Pulley up and out of the assembly while Pulley Shaft #2 is withdrawn from the assembly (See Figure 4-30 b).



**Figure 4-30** Pulley Shaft Removals


- Remove the two (2) E-Clips securing the ends of the Mover Worm Gear Shaft (See Figure 4-30 c).
- Pull the Mover Worm Gear Shaft out of the assembly along with the Final Mover Gear, Parallel Pin and E-Clip attached to it.
- Push each end of the three (3) Pulley Shafts out one at a time as illustrated in Figure 4-31 (a), and move their respective pulleys to the side wall.



**Figure 4-31** Mover Worm Gear Shaft Removal


- Push the end of the Pulley Shaft in, and pull it out in the direction indicated by the arrow shown at the Figure 4-31 (b) location.
- Lift the two (2) freed Transport Pulleys up and out of the assembly (See Figure 4-31 c).

12. Remove the three (3) E-Clips securing the Transport Drive Shaft end and internal Drive Pulleys from Transport Drive C (See Figure 4-32 a).
13. Pull the Transport Drive Shaft out and remove the two (2) Drive Pulleys along with the two (2) adjacent Parallel Pins all up and out of the assembly as the Transport Drive Shaft is withdrawn (See Figure 4-32 b).



**Figure 4-32 Transport Drive Shaft Removal**

14. Push the end of Pulley Shaft #2 in, and pull it out in the direction indicated by the arrow shown at Figure 4-32 (c), and remove the two (2) Transport Pulleys up and out of the assembly as Pulley Shaft #2 is withdrawn.
15. Remove the five (5) E-Clips securing the end and internal Drive Pulleys on Transport Shaft #2 of Transport Drive C.




**Figure 4-33 Drive Belt Removal**

16. Pull Transport Shaft #2 out of Transport Drive C (See Figure 4-33 a).
  17. Lift Drive Pulleys #1, #2 and #3 and their adjacent two (2) Parallel Pins up and out of the assembly as Transport Shaft #2 is withdrawn (See Figure 4-33 b).
  18. Remove the three freed Timing Belts from the assembly.
- NOTE:** Reinsert the Parallel Pins into Drive Pulleys #1 and #2 only! No Parallel Pin is required for Drive Pulley #3.

### Transport D Solenoid Removal

Perform the following steps to remove the UBA Transport Drive D Solenoid:

1. Remove the four (4) Solenoid Base mounting screws securing the Solenoid Base Cover to Transport Guide D (See Figure 4-34 a).



**Figure 4-34 Transport Guide D Solenoid Removal**


2. Remove the Solenoid Base Cover.
3. Remove the two (2) Solenoid mounting screws from the bottom side of Transport Guide D and lift the Solenoid up and out of the assembly (See Figure 4-34 b).

### Cash Box Handle and Intelligent Cash Box ICB Module Unit Disassembly

#### CASH BOX HANDLE REMOVAL

Perform the following steps to remove the UBA Standard and Intelligent Cash Box (ICB) Handle:


1. Remove the two (2) Cash Box Handle mounting screws (See Figure 4-35).
2. Remove the Handle Caps and lift the Handle off of the assembly.



**Figure 4-35 Cash Box Handle Removal**  
**ICB MODULE REMOVAL**

Perform the following steps to remove the UBA ICB Module:

1. Remove the two (2) module mounting screws securing the ICB Module Box Cover to the ICB Module Box Assembly (See Figure 4-36 a).




**Figure 4-36 ICB Module Removal**

2. Remove the two (2) screws that mount the ICB Module Box onto the Cash Box (See Figure 4-36 b).
3. Remove the two (2) screws that attach the ICB Module circuit board onto the ICB Module Box Assembly (See Figure 4-36 c).

### Cash Box Sensor Board Removal

1. Remove the Transport Guide E Back Cover by pressing down on the curved arrow area indicated in Figure 4-37a.
2. Remove the two (2) Cash Box Sensor Board mounting screws (See Figure 4-37 b).




**Figure 4-37 Cash Box Sensor Removal**

3. Carefully lift the Cash Box Sensor Board up; disconnect its Harness Connector Plug, and remove the Cash Box Sensor Board from the Transport Guide E Assembly.

### Pusher Mechanism Unit Disassembly


Perform the following steps to disassemble the UBA Pusher Mechanism Unit:

1. Open the Cash Box lid and remove the two (2) internal Pusher Mechanism Unit Mounting Screws from the back inside wall of the Cash Box (See Figure 4-38).
2. Slide the Pusher Mechanism Unit out of the assembly in the direction of the large arrow in Figure 4-38.



**Figure 4-38 Pusher Mechanism Unit Removal**

3. Remove the six (6) Pusher Mechanism Mounting Screws from the sides of the assembly as shown in Figure 4-39.
4. Separate the Pusher Mechanism Unit upward and out of the Transport in the direction of the large arrow in Figure 4-39.




**Figure 4-39** Pusher Mechanism Separation

### Final Timing Belt Disassembly


Perform the following steps to remove the final UBA Timing Belts:

1. Remove the two (2) screws located on each side of the Belt Housing.
2. Remove the Cover Roller in the direction of the large arrow in Figure 4-40.




**Figure 4-40** Cover Roller Removal

3. Remove the two (2) "Drive Gear (24)" E-Clips, its related Parallel Pin, and its Ø 6B Bushing (See Figure 4-41 a).
4. Remove the E-Clip retaining the Bracket Gear assembly in place (See Figure 4-41 b1).
5. Lift the Bracket Gear assembly up and off the Transport Unit (See Figure 4-41 b2).
6. Remove "Gear M1-Z12 (P-1)" (See Figure 4-41 c).



**Figure 4-41** Timing Belt Removal Access

7. Remove the second Ø 6B Bushing E-Clip retainer, then remove the second Ø 6B Bushing (See Figure 4-41 d).
8. Release the Left Pressure Spring's tension in the Shaft Roller Pit as indicated in the Figure 4-41 (e) exploded view.
9. Pull the Right Pusher Guide upward, and remove the Timing Belts.(See Figure 4-42).



**Figure 4-42** Timing Belt Removal

The Disassembly Procedure is now complete. Reverse all of the proceeding instructions to reassemble any of the components described during this disassembly procedure.

THIS PAGE INTENTIONALLY LEFT BLANK

# UBA® Series

## Universal Bill Acceptor (UBA-1x-SS & UBA-x4-SS/SU)

### Section 5

#### 5 WIRING DIAGRAMS

This chapter provides the Universal Bill Acceptor Series (UBA) wiring diagrams and component parts lists for the following items:

- UBA Primary Components
- System Wiring Diagrams.

#### UBA Primary Components Parts Diagram




Figure 5-1 Universal Bill Acceptor (UBA) Primary Components

THIS PAGE INTENTIONALLY LEFT BLANK

## UBA-1x-SS SYSTEM WIRING DIAGRAM





Figure 5-2 UBA-10-SS Bill Acceptor System Wiring Diagram

**THIS PAGE INTENTIONALLY LEFT BLANK**

NOTE: If you intend to print this document, please replace this page with the same page numbered 11x17 inch fan-fold page present at the end of this PDF file.

**UBA-1X-SS System Wiring Diagram (Continued 1)****Figure 5-3 UBA-11/12-SS Bill Acceptor System Wiring Diagram**

**THIS PAGE INTENTIONALLY LEFT BLANK**

NOTE: If you intend to print this document, please replace this page with the same page numbered 11x17 inch fan-fold page present at the end of this PDF file.

## UBA-14/24 System Wiring Diagram (Continued 2)




Figure 5-4 UBA-14-SS &amp; UBA-24-SS/SU External Connector Interface Circuit Wiring Diagram

**THIS PAGE INTENTIONALLY LEFT BLANK**

NOTE: If you intend to print this document, please replace this page with the same page numbered 11x17 inch fan-fold page present at the end of this PDF file.


**UBA-14/24 System Wiring Diagram (Continued 3)**

1

2

3

4



|     |      |             |         |          |  |  |   |         |                                       |
|-----|------|-------------|---------|----------|--|--|---|---------|---------------------------------------|
| 6   | .    | .           |         |          |  |  |   | MODEL   | <b>U B A - * * - * *</b>              |
| 5   | .    | .           |         |          |  |  |   | TITLE   | 24V/13V CONVERT &<br>RS232C I/F BOARD |
| 4   | .    | .           |         |          |  |  |   | DWG No. | <b>3 2 4 0 - 0 1 - 1 3 A</b>          |
| 3   | .    | .           |         |          |  |  |   |         |                                       |
| 2   | .    | .           |         |          |  |  |   |         |                                       |
| 1   | .    | .           |         |          |  |  |   |         |                                       |
| No. | DATE | INFORMATION | CHECKED | RELEASED |  |  |   |         | JAPAN CASH MACHINE CO., LTD.          |
| 1   |      |             | 2       |          |  |  | 3 |         | 4                                     |

**Figure 5-5 UBA-14/24 Optional Conversion Board Interface Circuit Wiring Diagram**

**THIS PAGE INTENTIONALLY LEFT BLANK**

NOTE: If you intend to print this document, please replace this page with the same page numbered 11x17 inch fan-fold page present at the end of this PDF file.

# UBA® Series

## Universal Bill Acceptor (UBA-1x-SS & UBA-x4-SS/SU)

### Section 6

## 6 PROGRAMMING, CALIBRATION & TEST

This section provides Flash Memory Download Programming, Calibration, and Performance Testing instructions for the Universal Bill Acceptor (UBA) Series. This section contains the following information:

- Workbench Tool Requirements
- Software Download Preparation
- Software Downloading Procedure
- Programming Instructions
- Calibration Procedures
- Performance Tests

### Workbench Tool Requirements

The following tools are required to perform a Workbench Software Download (See Figure 6-2):

- JCM Universal Bill Acceptor (UBA)
- JCM External Power Supply (Part No. 701-000148) or equivalent
- PC containing a USB port (OS: Windows 2000/XP)

- USB Cable (A type Male to B Type Male) (See Figure 6-1).
- The latest .ZIP compressed UBA Download Program (V1.11 or later).




Figure 6-1 Download USB Cable Requirement

### Software Download Preparation

The following instructions describe how to decompress and store a downloaded program onto a personal computer (PC) for eventual installation into the Universal Bill Acceptor:

1. Refer to the Figure 6-2 interconnection diagram to properly connect the various cables and wiring harnesses to the UBA.





Figure 6-2 Required Download Workbench Tools



**Warning: Make sure the External Power Supply is OFF when connecting the harness to the UBA. Failure to do so may cause electrical shock and/or permanent damage to the equipment.**

- Figure 6-3 illustrates the UBA's DIP Switch, LED indicators and external port locations.




**Figure 6-3 UBA DIP Switch & Port Location**

## Software Downloading Procedure

### Program Installation

The following PC initialization functions are required prior to downloading software.


- Create and name a new folder on your PC.
- Decompress the ZIP file and save the expanded file program contents in the file folder just created.
- Open the folder and Double-Click on "Setup.exe" of the expanded UBA Program.
- The **UBA Downloader** screen shown in Figure 6-4 will appear. Click the **Next >** button to continue the installation.



**Figure 6-4 Initial Setup Screen**

- Enter a User Name: and Organization: in the fields displayed by the "Customer Identification Screen" and Mouse-click on the **Next >** Screen Button as shown in Figure 6-5.


**NOTE:** One of two selections for a application installer must also be made below the information fields.



**Figure 6-5 Customer Information Screen**

- Confirm the folder name given during Step 1 to install the UBA Downloader and Mouse-click on the **Next >** Screen Button as shown in the Figure 6-6 "Destination Folder" Screen.


**NOTE:** If the folder name given during Step 1 does not appear under the Install UBA Downloader To: line, Mouse-click on the **Change...** **Screen Button** and find the correct folder on the PC.



**Figure 6-6 Destination Folder Screen**

- The Ready to Install the Program screen shown in Figure 6-7 will now appear. If the folder selection and customer information is correct, Mouse-click on the **Next >** **Screen Button**.

Screen Button to start the installation procedure. If not, Mouse-click on the <Back Screen Button, and re-enter the information until it is correct.



**Figure 6-7 Ready to Install Screen**

8. During the installation of the UBA Downloader, the Figure 6-8 "Installing UBA Downloader" Screen will appear containing a left-to-right Status: Barograph occurring at screen center.
9. When the install process is complete, Mouse-click on the Next > Screen Button to complete the installation.



**Figure 6-8 Software Installing Screen**


10. The Figure 6-9 Screen will appear when the Software installation process is complete. Mouse-click on the Finish Screen Button on the Figure 6-9 Screen to exit the InstallShield Wizard Screen.



**Figure 6-9 Installation Finished Screen  
Programming Instructions**

Once the UBA Software Program has been installed onto the PC Computer, use the following steps to install the information into the UBA Flash Memory:

1. Set all UBA Front Panel DIP Switches to OFF, and
  2. Supply power to the UBA.
  3. Start the UBA Downloader Application from your PC's Start → Program → [JCM named] file folder.
- When the application opens, the Figure 6-10 Screen will appear



**Figure 6-10 Initial Program Installation Screen**

4. Mouse-click on the Browse Screen Button and select the Software shown on the PC Screen (See Figure 6-11) to be downloaded into the UBA flash memory Then click the Download Screen Button located at Screen Center to begin the Software downloading procedure.
5. When the Flash ROM download has completed, Click the button to close the UBA Downloader file (See Figure 6-12).

*NOTE: For details involving Jumper settings, refer to See "Jumper Configurations" on page 2-9 of Section 2 regarding the setting of any UBA Unit Jumpers.*




Figure 6-11 PC Browse Screen



Figure 6-12 Installation Complete Screen



*NOTE: Once the software is downloaded into the UBA, it is recommended that Banknote acceptance be tested using the new software to confirm that the download was successful. (See Test "No. 8 Bill Acceptance Test" on page A-11 of Appendix A regarding Bill Acceptance Testing).*

## Forced Download Requirements

If the UBA does not accept a download in the normal manner as previously described, a Forced Download may be required. To perform a Forced Download, proceed as follows:

1. Remove Power from the UBA Unit.
2. Turn Dip Switches #6, #7 & #8 ON.
3. Apply Power from the UBA Unit. An active Forced Download Mode will be indicated by the two (2) LEDs (Red & Green) will be alternately blinking.
4. At this point, proceed with the previously described Normal Downloading Procedure.

## Calibration Procedures

### Calibration Description

Calibration sets a starting reference point for all optical and magnetic sensors within the unit.

This task can be accomplished at the host unit or at a workbench.

### Calibration Tool Requirements

The following equipment and tools are required for workbench calibration: (See Figure 6-13).

- JCM Universal Bill Acceptor (UBA)
- JCM External Power Supply (JAC Part #701-000148) or equivalent




Figure 6-13 Required Calibration Workbench Tools

- PC containing a USB port (OS: Windows 2000/XP)
- White Reference Paper (JAC Part #501-000167R, EDP #107724)
- Black Reference Paper (JAC Part #501-000166R, EDP #107725)
- UV Reference Paper (JAC Part #501-000164R, EDP #110664)

- Mag Tool Kit (JAC Part #701-000086RA). Kit includes Calibration Papers (White, Black & UV) and the Mag Tool as well.
- MAG Tool US Power Cable (JAC Part #300-100007RA).
- Adjustment Program (ADJTOOL\_V1.06-4.exe, comm.ini and adj.ini) available at [www.jcmglobal.com](http://www.jcmglobal.com).

## When to Calibrate

1. After a Bill Acceptor component has been disassembled for repair.
2. After a sensor board has been replaced.
3. If a CPU Board is replaced.

## Initial Settings

1. Make sure that the UBA jumper setting are in the photo-coupler isolation position.
2. Connect the two External Power Supply Communications cables between the UBA and PC Serial Port respectively (See Figure 6-13).
3. Set UBA Front Panel DIP Switch 8 to ON, and supply power to the External Power Supply unit.
4. Create and name a new folder on your PC
5. Save the decompressed "ADJTOOL\_Vxxx.exe", "comm.ini" and "adj.ini" adjustment programs in the newly created folder.

## Adjustment Procedure

To begin adjusting the UBA Unit proceed as follows:

 *NOTE: The UBA Unit must be in a Frame for calibration!*

1. Double click on the latest version of the UBA\_ADJTOOL\_Vxxxx.exe application and the Figure 6-14 Screen will appear.




Figure 6-14 Opened UBA\_ADJTOOL File Screen

2. Check that the PC's COM Port number being used agrees with the Port to which the UBA

is connected by clicking on the **COM** Pull-down Tab (See Figure 6-14 a) and selecting "RS232C".

3. In the Dialog Box that appears (See Figure 6-15), select the COM Port to which the UBA is connected, and Mouse-click on the **Select**  Screen Button (See Figure 6-15).




Figure 6-15 COM Port Selection Screen

4. Turn UBA DIP Switch #8 **ON**, apply power to the UBA, then turn DIP Switch #8 **OFF**.
5. Click **START** to begin the UBA Adjustment program (See Figure 6-14 b). The automatic Motor Speed Check Test will run, and a Dialog Box Window will then ask for the "White" Reference paper to be set in place (See Figure 6-16).




Figure 6-16 White Reference Test Screen

6. Open the UBA's Upper Guide, Insert the White Reference Paper (See Figure 6-18 ①), firmly close the Guide Cover (See Figure 6-18 ②) and Mouse-Click on the **OK**  Screen Button.







Figure 6-17 Black Reference Test Screen

**Figure 6-18** White Test Paper Insertion Request


- After a short period, the Dialog Box Window will indicate "Black Adjustment" (See Figure 6-17). Open the UBA's Upper Guide, remove the White Reference Paper and insert the Black Reference Paper (See Figure 6-19 ①), firmly close the guide (See Figure 6-19 ②) and Mouse-click the OK Screen Button again.

**Figure 6-19** Black Test Paper Insertion Request

- Repeat the White and Black Reference Paper steps as instructed on the Screen until the "UV Adjustment" Screen shown in Figure 6-20 is displayed. Open the UBA Upper Guide, remove the existing test Reference Paper and insert the UV Reference Paper in its place; then Mouse-click on the OK Screen Button again.


**Figure 6-20** Set UV Reference Test Screen

- Insert the UV Reference Paper so it covers the White Plastic Area at the rear center of the Lower Transport path (See Figure 6-21 ①) with the Label facing UP, and firmly close the Upper Guide as shown in Figure 6-21 ②, then Mouse-click on the OK Screen Button again.


**Figure 6-21** UV Test Paper Insertion Request

**CAUTION: Do not insert the UV Reference paper past the curved area of the Transport, an error will occur if the UV Reference paper is inserted in too far.**

- When the "Adjustment Without Reference Paper" Screen appears, open the Upper Guide and remove the UV Reference Paper, then firmly close the Upper Guide and Mouse-click on the OK Screen Button again (See Figure 6-22).

**Figure 6-22** Remove UV Reference Test Screen

- When the White Adjustment Screen reappears, insert the White Reference paper and again Mouse-click on the OK Screen Button.
- When adjustment of all of the Optical Sensors is complete, the "MAG HEAD Adjustment" Screen will appear (See Figure 6-23).



**Figure 6-23 MAG HEAD Adjustment Dialog Screen**



**Figure 6-24 MAG HEAD Adjustment Successful Screen**

13. Insert the Mag Head Test Board into the UBA. Set the Mag Head Test Board so the middle line is located just above the Roller located on the Lower Tray, then close the guide firmly and Mouse-click on the **OK** Screen Button.
14. Move the Mag Head Test Board back and forth, in and out slightly, to find the peak value. Find the position where the "GAIN1" value enters a range within -5P in relation to the peak value, then press the "Space" Bar.  
NOTE: The average peak value range is approximately 20P to approximately 35P. Use this value only for reference and make sure to find the true peak value using your particular Acceptor Unit.
15. When the MAG HEAD Adjustment is complete, the "ADJUSTMENT SUCCESSFUL!!" Screen shown in Figure 6-24 will appear.
16. Mouse-click on the **OK** Screen Button again, and this calibration process will be complete.

Calibration Error Codes that may occur during these procedures are listed in Table 6-1.

**Table 6-1 Calibration Error Table**

| Error Code | Displayed Message                 | Description/Cause   |
|------------|-----------------------------------|---|
| 4-A        | Gain Error (Value over 4.3V)      | Light receiving Adjustment Error. Check for dirty or wrong Calibration Paper use.   |
| 4-B        | Adjustment Error                  | Sensor Light Quantity Adjustment Error. Replace either the Upper or Lower Sensor PCB  |
| 4-C        | Black Level Error                 | Sensor Light Quantity Adjustment Error. Ensure that the Black Reference Paper is properly inserted.   |
| 4-E        | Gain Error                        | Light Receiving Adjustment Error. Clean Sensors. Replace Upper or Lower Sensor PCB.   |
| 4-G        | Front/Back/Pbin/Width Level Error | Triggering Sensor Light Receiving Error. Clean the Sensor. Wrong Calibration Paper being used during UV Sensor Adjustment. Replace the Exit Sensor.<br>NOTE: The UBA must be installed in a Frame during Calibration. |
| 6-A        | Offset Error                      | Light Receiver Circuit Abnormality. Clean Sensors. Replace either the Upper or Lower Sensor PCB.  |
| 6-B        |                                   |   |
| 6-C        | MAG                               | Magnetic Sensor Adjustment Error. Replace the Upper Sensor PCB.   |
|            |                                   |   |
| No Code    | Gain Max Limit Over Error         | Sensor Abnormality. White Reference Paper not inserted correctly.   |
|            | Bar Gain Max Limit Over Error     | Sensor Abnormality. For UBA 1x, Replace the Upper Sensor PCB. For UBA 24, Replace the Lower Sensor PCB  |
|            | UV Gain Max Limit Over Error      | Sensor Abnormality. Clean UV Sensor and White Reference Block. Ensure UV Reference Paper is inserted with its Label up, covering the White Reference block.   |
|            | A/D Data Level Error              | Light Receiving Level Error. Ensure the White Reference Paper is inserted completely and correctly placed   |
|            | Pbin/Width D/A Error              | Triggering Sensor Adjustment Error. Clean PB In-Sensor or Reference Paper is not inserted correctly   |
|            | Motor Speed Error                 | Transport Motor Speed Error   |
|            | EEPROM Write Error                | Adjustment Value Writing Error. Replace the Processor PCB.  |


## UBA-USB Tool Suite Overview

The UBA-USB Tool Suite is a Software Application allowing Software updating, performance data retrieval and performing Calibration of the UBA Unit using the USB Port of the Acceptor to download.

Full functionality of the UBA-USB Tool Suite was implemented in Software Versions v1.71-16, v1.76-17, v1.77-17, v1.76-24 and v1.76-13 or later.

However, the download function can only be accessed on older version of UBA Acceptor Software.

The USB Tool Suite Application is available for download from the JCM Website at: <http://www.jcmglobal.com/en/support/downloads.aspx> (See Figure 6-25).



**Figure 6-25** UBA-USB Tool Suite Opening Screen

### Installing the UBA Tool Suite Application

To begin installing the UBA-USB Application proceed as follows:

1. Open the Folder where the UBA-USB Tool Suite Application is located on the PC.
2. Extract the compressed files located in the Folder into a separate named Folder.
3. Double-click on the "Setup" Application to install the UBA-USB Tool Suite onto your PC.

### Installing the UBA Device Drivers



*NOTE: If the UBA Downloader Program was previously installed, the Device Drivers are ready for use.*

To install the JCM-UBA Device Drivers perform the following steps:

1. Connect power to the UBA.
2. Connect a Male "A" to Male "B" USB Cable between the UBA-USB Port and an open, unassigned USB Port on the PC.
3. When the PC recognizes that a new device is attached to it, it will prompt the user to install the Device Drivers (See Figure 6-26).
4. Mouse-click on the Next > Screen Button and let the PC automatically search

for the Drivers; if located, the PC will immediately install the proper Driver(s). Follow the prompts presented on the Screen.




**Figure 6-26** UBA-USB Driver Install Screen

5. If the Drivers cannot be located, select the "Install from a list or specific location (Advanced)" Radio Button, Mouse-click on the Next > Screen Button, then Browse to where the UBA-USB Tool Suite Program is loaded. The required Drivers should be in the same Folder.

### Connecting the UBA Unit


The UBA can be either installed in a game or on the Workbench when using the UBA-USB Tool Suite.

1. Apply power to the UBA.
2. Open the UBA-USB Tool Suite Program (See Figure 6-27).



**Figure 6-27** Re-Opened UBA-USB Tool Suite Screen

3. Connect the USB Cable between the UBA and the PC.
4. When communications is established, the various Form Fields will be filled-in with data from the UBA Unit (See Figure 6-28).



**Figure 6-28** UBA-USB Tool Suite Standard Screen

### UBA USB Tool Suite Functions

The three functions available with the UBA-USB Tool Suite are as follows:

- Download
- Statistics
- Sensor Adjustment.


#### Download

The download program is used to update the Software in a UBA Unit.

When selecting the download option, the UBA Downloader Program will open as shown in Figure 6-29.

To load a specific data object into a UBA proceed as follows:

1. Mouse-click on the Browse Screen Button and select the data file desired to load into the UBA.



**Figure 6-29** UBA Downloader Program Screen

2. Start the download, by Mouse-clicking on the Download Screen Button.

For full information on updating UBA Software, refer to "Software Download Preparation" on page 6-1 of this Service Manual.


### Statistics

The "Statistics" Tab Selection is used to read AccLoad Statistics from within the UBA Unit (See Figure 6-31 a).

When the "Statistics" Tab is selected, the AccLoad Screen shown in Figure 6-31 will appear.

To "Read" data back from the UBA Unit, Mouse-click on the **Read** Screen Button → (See Figure 6-31 b).

Information on the "Accload Program" is available in the "ACLOAD Quick Reference Guide", available on JCM Global Website.




**Figure 6-30** UBA-USB Tool Suite ACCLoad Screen

### Sensor Adjustment

The Sensor Adjustment Program is used to calibrate the UBA Unit.

To open the Sensor Adjustment Program, select the Sensor Adjustment Option in the UBA-USB Tool Suite Application (See Figure 6-31).



**Figure 6-31** UBA-USB Tool Suite Sensor Adjustment Screen

To start the Calibration process, Mouse-click on the START Screen Button to begin the UBA Calibration Process (See Figure 6-31 a).

For complete details and requirements concerning the Calibration Program, refer to "Calibration Description" on page 6-4 of this UBA Series Operation and Maintenance Manual.

THIS PAGE INTENTIONALLY LEFT BLANK

# UBA® Series

## Universal Bill Acceptor (UBA-1x-SS & UBA-x4-SS/SU)

### Section 7

#### 7 EXPLODED VIEWS AND PARTS LISTS

This section provides product exploded views and parts lists for the Universal Bill Acceptor (UBA) Series. This section contains the following information:

- Entire UBA-10/11/12 Unit & UBA-14/24/25 Unit Views and Parts Lists

- Transport Unit Cover Assembly View and Parts
- Transport Unit Assembly View and Parts
- Frame Unit View and Parts
- Cash Box Unit View and Parts.

#### Entire UBA-10/11/12-SS & 14/24/25-SS/SU Unit Views and Optional Parts




Figure 7-1 Entire UBA-10/11/12-SS & 14/24/25-SS/SU Units, Accessory & Optional Part Exploded Views

## Entire UBA-10/11/12-SS Unit Parts List

Table 7-1: Entire UBA-10/11/12-SS & UBA-14/24/25-SS/SU Unit, Accessories & Optional Parts List

| <b>Ref №.</b> | <b>EDP Number</b> | <b>JAC Part №.</b>         | <b>Description</b>                                      | <b>Remark</b>                           |
|---------------|-------------------|----------------------------|---|---|
| 1             | 116216*           | 550-100453R                | UBA TRANSPORT UNIT R                                    | For UBA-10/11/12 (NO CPU Board).        |
|               | 138425*           | Configuration<br>Dependant | UBA TRANSPORT UNIT (with 3.3 V - 8 Meg Flash Memory) R  | For UBA-10/11/12 (CPU Board included.)  |
|               | 117754*           | 550-100455R                | UBA TRANSPORT UNIT (USB I/F applicable) R               | For UBA-14/24 (CPU Board included.)     |
| 2             | 106446*           | 200-200483R                | UBA FRAME UNIT HK R                                     |   |
| 3             | 128680            | 808-001036R                | UBA-SS CASH BOX MP6 R                                   | Standard Cash Box                       |
| 4             | 128679            | 608-001013R                | UBA-SS CASH BOX IT MP6 R                                | Intelligent Cash Box                    |
| 5             | 127891            | 808-001062R                | UBA CASH BOX L  | Large Plastic Cash Box                  |
|               | 128875            | 608-001026RA               | UBA CASH BOX IT L                                       | Large Plastic Intelligent Cash Box      |
| 6             | 060455            | 400-100029                 | OEM INTERFACE HARNESS R                                 | For UBA-10/11/12, OEM Interface         |
|               | 062897            | 400-100027R                | ID-003 INTERFACE HARNESS R                              | For UBA-10/11/12, ID-003 Interface      |
|               | 117623            | 400-100251R                | USB INTERFACE HARNESS (without Cable Clip) R            | For UBA-14, OEM Interface without SL-5N |
|               | 120120            | 400-100561RA               | USB/ID-003 INTERFACE HARNESS (with Cable Clip) R        | For UBA-14, OEM Interface with SL-5N    |
|               | 128075            | 400-100567RA               | USB Interface Harness without Cable Clamp               | For UBA-24                              |
| 7             | 104013            | 186-3000012R               | 3x12 SCREW with WASHER (Small)                          |   |
| 8             | 113944            | 900-101010RA               | UBA FACE UNIT A   |   |
|               | 113945            | 902-031085RA               | UBA FACE UNIT 1   |   |
|               | 113946            | 902-100493R                | UBA FACE UNIT 2   |   |
| 9             | 117752            | 900-100308R                | SL-N5 NYLON CLIP  | (For UBA-14/24 I/F Only)                |
| 10            | 063250            | 171-504033R                | M2.6x6 BINDING SELF TIGHTENING PHILLIPS SCREW           |   |
| ACC1          | 059086            | 200-100980R                | KEY SPACER R  |   |
| ACC2          | 103158            | 200-200367RA               | PLATE LOCK KEY  |   |
| ACC3          | 130356            | 200-100991R                | PLATE LOCK KEY (Narrow)                                 |   |
| ACC4          | 104014            | 186-300012R                | KEY HOLE CAP  |   |
| OP1           | 135327            | 900-200423R                | THUMB TURN A (Knob)                                     |   |
| OP2           | 135328            | 900-200424R                | THUMB TURN B (Sleeve)                                   |   |
| OP3           | 135329            | 900-200425R                | THUMB TURN NUT  |   |
| OP4           | 135330            | 900-200426R                | THUMB TURN CAM (Tang)                                   |   |
| OP5           | 056165            | 171-261003R                | 2.6x8 BINDING SELF TIGHTENING PHILLIPS SCREW            |   |
| OP6           | 122467            | 300-500007R                | 24VDC/13.5VDC and RS-232C SIGNAL LEVEL CONVERSION BOARD |   |
| OP7           | 123523            | 300-200139R                | RS-232C SIGNAL LEVEL CONVERSION BOARD                   | (For UBA-14/24 Only)                    |
| OP8           | 136243            | 300-200140R                | ccTALK I/F CONVERSION BOARD                             |   |
| OP9†          | 133297            | 300-100398R                | 24VDC/13.5VDC+USB SIGNAL LEVEL CONVERSION BOARD         | (For UBA-14/24 Only)                    |

\*. An interim EDP Number. Contact your JCM Sales Representative prior to ordering this part.

†. Refer to Table 7-6 on page 7-23 of this Section for the availability of Additional Optional Parts.

## Transport Unit Exploded Views




Figure 7-2 UBA Transport Cover Assembly Exploded View (Part 1)

## Transport Unit Exploded Views (Continued 1)






Figure 7-3 UBA Transport Unit Exploded View (Part 2)

**Transport Unit Exploded Views (Continued 2)****Figure 7-4 UBA Transport Unit Exploded View (Part 3)**

**Transport Unit Exploded Views (Continued 3)****Figure 7-5 UBA Transport Unit Exploded View (Part4)**

## Transport Unit Parts List

Table 7-2: UBA Transport Unit Parts List

| Ref N <sup>o</sup> . | EDP Number | JAC Part N <sup>o</sup> . | Description                                   | Qty. | Remark                   |
|----------------------|------------|---------------------------|---|------|--------------------------|
| 101                  | 109101     | 900-100846R               | UBA TRANSPORT GUIDE C                         | 1    |                          |
| 102                  | 109099     | 900-100368R               | UBA SENSOR LENS A                             | 2    |                          |
| 103                  | 109098     | 900-100596R               | UBA SENSOR LENS B                             | 4    |                          |
| 104                  | 102974     | 900-100626R               | UBA MAG ROLLER                                | 1    |                          |
| 105                  | 063353     | 250-100531                | MAG SPRING                                    | 1    |                          |
| 106                  | 102997     | 200-101108RA              | MAG ROLLER PIN                                | 1    |                          |
| 107                  | 102764     | 900-100538R               | UBA SENSOR COVER                              | 1    |                          |
| 108                  | 102776     | 900-100630R               | UV PARTITIONER                                | 1    |                          |
| 109                  | 102773     | 900-100631R               | LIGHT GUIDE A                                 | 1    |                          |
| 110                  | 102772     | 900-100634R               | LIGHT GUIDE B                                 | 1    |                          |
| 111                  | 116204     | 300-100346R               | ENTRANCE SENSOR R                             | 1    |                          |
| 112                  | 103006     | 200-100854                | TRANSPORT DRIVE SHAFT                         | 1    |                          |
| 113                  | 091168     | 900-100946RA              | PULLEY D                                      | 5    |                          |
| 114                  | 104296     | 900-100616R               | TIMING BELT                                   | 2    | Recommended Service Part |
| 115                  | 103003     | 200-101111RA              | TRANSPORT SHAFT 2                             | 1    |                          |
| 116                  | 104297     | 900-100648R               | TIMING BELT                                   | 1    | Recommended Service Part |
| 117                  | 103007     | 200-101112RA              | PULLEY SHAFT                                  | 4    |                          |
| 118                  | 091169     | 900-100947RA              | TRANSPORT PULLEY R                            | 8    |                          |
| 119                  | 119302     | 900-100948RA              | PULLEY ROLLER R                               | 4    |                          |
| 120                  | 103009     | 200-101113RA              | PULLEY SHAFT 2                                | 2    |                          |
| 121                  | 102783     | 900-100949RA              | PULLEY MOVER P                                | 1    |                          |
| 122                  | 143337     | 900-200202RA              | LOWER SENSOR SPACER                           | 1    |                          |
| 123                  | 103983     | 200-100842R               | UBA MOVER SCREW                               | 1    |                          |
| 124                  | 102970     | 900-100657                | UBA FINAL MOVER GEAR                          | 1    |                          |
| 125                  | 119306     | 900-100639R               | MOVER BEARING R                               | 2    |                          |
| 126                  | 102999     | 200-101109RA              | MOVER GEAR SHAFT                              | 1    |                          |
| 127                  | 102969     | 900-100658                | UBA 2ND MOVER GEAR                            | 1    |                          |
| 128                  | 103923     | 451-000071R               | CENTERING MOTOR ASSY.                         | 1    | Recommended Service Part |
| 129                  | 103878     | 400-100501R               | ENTRANCE SENSOR/CENTERING HOME SENSOR HARNESS | 1    |                          |
| 130                  | 106068     | 200-200327RA              | GROUND PLATE 1                                | 1    |                          |
| 131                  | 102763     | 200-100845R               | UBA MOVER GUIDE 1                             | 1    |                          |
| 132                  | 102762     | 200-100846R               | UBA MOVER GUIDE 2                             | 1    |                          |
| 133                  | 116202     | 300-100324R               | EXIT SENSOR R                                 | 1    |                          |
| 134                  | 102782     | 900-100597R               | FRONT OUTPUT SENSOR COVER                     | 1    |                          |
| 135                  | 102761     | 900-100641R               | REAR SENSOR GUIDE                             | 1    |                          |
| 136                  | 104072     | 451-000073R               | UBA ANTI-PULLBACK MOTOR ASSY.                 | 1    | Recommended Service Part |
| 137                  | 118800     | 900-100940R               | ANTI-PULLBACK MOTOR COVER                     | 1    |                          |
| 138                  | 091193     | 900-100632R               | ROLLER GEAR MOTOR R                           | 1    | Recommended Service Part |

**Table 7-2: UBA Transport Unit Parts List (Continued)**

| <b>Ref №.</b> | <b>EDP Number</b> | <b>JAC Part №.</b> | <b>Description</b>          | <b>Qty.</b> | <b>Remark</b>            |
|---------------|-------------------|--------------------|-----------------------------|-------------|--------------------------|
| 139           | 102971            | 900-100629R        | UBA 2ND ROLLER GEAR COVER   | 1           |                          |
| 140           | 103004            | 200-100840         | HORIZONTAL WORM GEAR SHAFT  | 1           |                          |
| 141           | 102753            | 900-100593R        | UBA TRANSPORT GUIDE B       | 1           |                          |
| 142           | 105234            | 300-500013RA       | ANTI-PULLBACK HOME SENSOR   | 1           |                          |
| 143           | 107846            | 900-100488         | ROLLER GUIDE HOME LEVER     | 1           |                          |
| 144           | 102976            | 900-100624         | ROLLER GUIDE HOME ROLLER    | 1           |                          |
| 145           | 103001            | 200-100849         | ROLLER LEVER SHAFT          | 1           |                          |
| 146           | 103023            | 250-100513R        | ANTI-PULLBACK LEVER SPRING  | 1           |                          |
| 147           | 103002            | 200-100923R        | ANTI-PULLBACK CLUTCH SHAFT  | 1           |                          |
| 148           | 102972            | 900-100627         | ROLLER GEAR CLUTCH          | 2           |                          |
| 149           | 103017            | 250-100512R        | ANTI-PULLBACK CLUTCH SPRING | 1           |                          |
| 150           | 103010            | 200-100841         | ROLLER GEAR SHAFT           | 1           |                          |
| 151           | 102754            | 900-100518R        | UBA TRANSPORT GUIDE A       | 1           |                          |
| 152           | 116208            | 300-100343R        | CENTERING HOME SENSOR R     | 1           |                          |
| 153           | 102979            | 119-000019R        | UBA ROLLER GUIDE BEARING    | 1           |                          |
| 154           | 109100            | 900-100306R        | UBA TRANSPORT GUIDE D       | 1           |                          |
| 155           | 091079            | 900-100636R        | SQUARE PRISM E3             | 3           |                          |
| 156           | 102981            | 900-100608R        | UV COVER                    | 1           |                          |
| 157           | 103000            | 200-101110RA       | TRANSPORT ROLLER SHAFT      | 2           |                          |
| 158           | 119299            | 900-100660R        | TRANSPORT ROLLER TR1        | 4           |                          |
| 159           | 108996            | 250-100484         | UBA TRANSPORT SPRING        | 1           |                          |
| 160           | 103833            | 200-1001114RA      | SPRING CLIP                 | 2           |                          |
| 161           | 119331            | 900-100654R        | ROLLER ROCKER SPRING        | 2           |                          |
| 162           | 102996            | 200-100924R        | MOVER ROLLER SHAFT          | 1           |                          |
| 163           | 119298            | 900-100661R        | MOVER ROLLER GUIDE          | 2           |                          |
| 164           | 103014            | 250-100507R        | UBA MOVER SPRING            | 1           |                          |
| 165           | 102977            | 900-100653R        | SPRING STOPPER              | 1           |                          |
| 166           | 102768            | 900-100651R        | UBA OPENING LEVER           | 1           |                          |
| 167           | 102771            | 900-100655R        | OPENING LATCH RIGHT         | 1           |                          |
| 168           | 102770            | 900-100656R        | OPENING LATCH LEFT          | 1           |                          |
| 169           | 103020            | 250-100526R        | OPENING LEVER SPRING        | 1           |                          |
| 170           | 102993            | 200-101058R        | OPENING LATCH SHAFT         | 1           |                          |
| 171           | 103016            | 250-100506R        | OPENING LATCH SPRING        | 2           |                          |
| 172           | 102756            | 900-100620R        | UPPER ROLLER LEVER          | 1           |                          |
| 173           | 102755            | 900-100621         | SOLENOID LINK LEVER         | 1           |                          |
| 174           | 102758            | 900-100619         | UPPER ROLLER SLIDER         | 1           |                          |
| 175           | 103013            | 200-100848         | MOVER BEAM SHAFT            | 1           |                          |
| 176           | 102995            | 200-100850         | SLIDER SHAFT                | 1           |                          |
| 177           | 103022            | 250-100503         | SOLENOID SPRING             | 2           |                          |
| 178           | 102998            | 200-100744R        | SOLENOID LEVER SHAFT        | 2           |                          |
| 179           | 104071            | 451-000070R        | SOLENOID ASSY. R            | 1           | Recommended Service Part |
| 180           | 102760            | 900-100637         | SOLENOID BASE               | 1           |                          |

**Table 7-2: UBA Transport Unit Parts List (Continued)**

| <b>Ref №.</b> | <b>EDP Number</b> | <b>JAC Part №.</b> | <b>Description</b>          | <b>Qty.</b> | <b>Remark</b>            |
|---------------|-------------------|--------------------|-----------------------------|-------------|--------------------------|
| 181           | 116213            | 300-100352R        | UPPER SENSOR BOARD R        | 1           | Recommended Service Part |
| 182           | 102750            | 900-100873         | UBA TRANSPORT GUIDE E       | 1           |                          |
| 183           | 102991            | 200-101105RA       | REAR GUIDE ROLLER SHAFT     | 1           |                          |
| 184           | 102975            | 900-100622         | UBA TRANSPORT ROLLER        | 2           |                          |
| 185           | 102992            | 200-101106RA       | REAR GUIDE SPRING SHAFT     | 1           |                          |
| 186           | 103018            | 250-100505         | REAR GUIDE ROLLER SPRING A  | 1           |                          |
| 187           | 103019            | 250-100504         | REAR GUIDE ROLLER SPRING B  | 1           |                          |
| 188           | 102766            | 900-100640         | WIRE TUNNEL                 | 1           |                          |
| 189           | 102781            | 900-100684         | CASH BOX SENSOR BOARD COVER | 1           |                          |
| 190           | 116206            | 300-100351R        | CASH BOX SENSOR R           | 1           |                          |
| 191           | 102990            | 200-101057R        | GUIDE FULCRUM PIN           | 2           |                          |
| 192           | 102994            | 200-101107RA       | TUNNEL SHAFT                | 1           |                          |
| 193           | 102767            | 900-100771R        | FRONT COVER                 | 1           |                          |
| 194           | 103008            | 200-101007R        | FRONT DOOR SHAFT            | 1           |                          |
| 195           | 103832            | 200-100855         | UBA TRANSPORT LATCH         | 1           |                          |
| 196           | 103005            | 200-100857         | STACKER CLUTCH SHAFT        | 1           |                          |
| 197           | 102793            | 900-100643         | 2ND STACKING GEAR           | 1           |                          |
| 198           | 103610            | 200-100847         | UNI-DIRECTIONAL CLUTCH      | 1           |                          |
| 199           | 118806            | 200-100853         | PLATE LOCK R                | 1           |                          |
| 200           | 102792            | 900-100642         | STACKING GEAR CLUTCH        | 1           |                          |
| 201           | 103015            | 250-100509         | CLUTCH SPRING               | 1           |                          |
| 202           | 104061            | 900-100652         | CLUTCH SPRING STOPPER       | 1           |                          |
| 203           | 102978            | 900-100674         | TRANSPORT BEARING LIMIT     | 1           |                          |
| 204           | 102968            | 900-100645         | FINAL STACKING GEAR         | 1           |                          |
| 205           | 102794            | 900-100647         | 3RD STACKING GEAR           | 1           |                          |
| 206           | 102967            | 900-100646R        | 4TH STACKING GEAR           | 1           |                          |
| 207           | 106441            | 451-000029R        | TRANSPORT MOTOR             | 1           | Recommended Service Part |
| 208           | 106443            | 451-000059R        | STACKING MOTOR              | 1           | Recommended Service Part |
| 209           | 102786            | 900-100663R        | TRANSPORT MOTOR GEAR        | 1           | Recommended Service Part |
| 210           | 102791            | 900-100644R        | STACKING MOTOR GEAR         | 1           | Recommended Service Part |
| 211           | 102989            | 142-090429R        | MOTOR SPACER                | 1           | Recommended Service Part |
| 212           | 102787            | 900-100692R        | 2ND TRANSPORT GEAR          | 1           |                          |
| 213           | 102788            | 900-100662R        | 3RD TRANSPORT GEAR          | 1           |                          |
| 214           | 102790            | 900-100688R        | FINAL TRANSPORT GEAR        | 1           |                          |
| 215           | 108154            | 200-100708         | GEAR PIN                    | 2           |                          |
| 216           | 102784            | 900-100633         | TRANSPORT GEAR COVER        | 1           |                          |
| 217           | 102765            | 900-100623         | UBA ROLLER GUIDE            | 1           |                          |
| 218           | 102973            | 900-100625R        | ROLLER GEAR GUIDE           | 1           |                          |
| 219           | 102980            | 900-100611R        | ROLLER GUIDE CAP            | 1           |                          |
| 220           | 118554            | 300-100325R        | ENCODER SENSOR R            | 2           |                          |

**Table 7-2: UBA Transport Unit Parts List (Continued)**

| <b>Ref №.</b> | <b>EDP Number</b> | <b>JAC Part №.</b> | <b>Description</b>   | <b>Qty.</b> | <b>Remark</b>                         |
|---------------|-------------------|--------------------|--|-------------|---------------------------------------|
| 221           | 103875            | 400-100503R        | ENCODER HARNESS R  | 2           |                                       |
| 222           | 103877            | 400-100505R        | CASH BOX SENSOR HARNESS  | 1           |                                       |
| 223           | 103873            | 400-100506         | UPPER SENSOR BOARD HARNESS R   | 1           |                                       |
| 224           | 103876            | 400-100512R        | ANTI-PULLBACK HOME SENSOR HARNESS R                                      | 1           |                                       |
| 225           | 116215            | 300-100332R        | LOWER SENSOR BOARD R   | 1           | Recommended Service Part              |
|               | 121260            | 300-200138R        | LOWER SENSOR BOARD R UBA-24  | 1           | UBA-24 ONLY Recommended Service Part  |
| 226           | 103872            | 400-100466         | HARNESS (with Connector)   | 1           | UBA-10/11/12                          |
|               | 117622            | 400-100309R        | HARNESS (USB Transport Interface)  | 1           | UBA -14                               |
| 227           | 103834            | 200-101054R        | UBA CONECTOR BRACKET   | 1           |                                       |
| 228           | 130799            | 300-100399R        | CPU BOARD (3.3VDC, 8Meg FLASH))  | 1           | UBA-10 Recommended Service Part       |
|               | 133432            | 300-100246R        | CPU BOARD (3.3VDC, 8Meg EPROM)   | 1           | UBA-11 Recommended Service Part       |
|               | 133433            | 300-100302R        | CPU BOARD (3.3VDC,16Meg FLASH)   | 1           | UBA-12 Recommended Service Part       |
|               | 112075            | 300-100301R        | CPU BOARD (3.3VDC USB Interface with applicable 16MB FLASH)              | 1           | UBA-14 Recommended Service Part       |
|               | 121267            | 300-500024RA       | CPU BOARD (USB Interface with applicable 16MB FLASH) DUAL BARCODE SENSOR | 1           | UBA-24 Recommended Service Part       |
|               | 142101            | 300-599926RA       | CPU BOARD (USB Interface with applicable 8MB FLASH) DUAL BARCODE SENSOR  |             | UBA-25 Recommended Service Part       |
| 229           | 103874            | 400-100504R        | LOWER SENSOR BOARD HARNESS R   | 1           | UBA -10/11/12/14                      |
|               | 128073            | 400-100695R        | LOWER SENSOR BOARD HARNESS for DUAL BARCODE SENSOR                       |             | UBA -24/25                            |
| 230           | 103879            | 400-100502R        | EXIT SENSOR HARNESS R  | 1           |                                       |
| 231           | 104059            | 200-101055R        | WIRE HOLDER  | 1           |                                       |
| 232           | 102769            | 900-100687R        | BACK COVER   | 1           |                                       |
| 233           | 102759            | 900-100772R        | TOP COVER  | 1           | UBA -10/11/12/14                      |
|               | 127826            | 900-200439R        | TOP COVER UBA-SU   | 1           | UBA -24/25                            |
| 234           | 102777            | 900-100519R        | RIGHT TRANSPORT COVER  | 1           |                                       |
| 235           | 102778            | 900-100767R        | LEFT TRANSPORT COVER   | 1           |                                       |
| 236           | 106031            | 200-100844R        | GROUNDING JACK PLATE   |             |                                       |
| 237           | 105984            | 200-100499R        | FRONT GROUNDING HARNESS  |             |                                       |
| 238           | 116197            | 300-100327R        | INTELLIGENT BOARD R  | 1           | UBA-10/11/12 Recommended Service Part |
| 239           | 107787            | 200-101115RA       | GROUND PLATE 2   | 1           |                                       |
| 240           | 103109            | 100-100012R        | PUSHER RIVET   | 1           |                                       |
| 241           | 033218            | 119-000011         | BEARING #SMF85ZZ   | 2           |                                       |
| 242           | 104050            | 119-000021R        | BEARING  | 2           |                                       |
| 243           | 080523            | 119-000022R        | BEARING  | 1           |                                       |

**Table 7-2: UBA Transport Unit Parts List (Continued)**

| <b>Ref №.</b> | <b>EDP Number</b> | <b>JAC Part №.</b> | <b>Description</b>                           | <b>Qty.</b> | <b>Remark</b>                           |
|---------------|-------------------|--------------------|--|-------------|---|
| 244           | 092949            | 900-100659         | CABLE TYE                                    | 4           |   |
| 246           | 104043            | 171-200203RA       | 2X3 BINDING FASTENER with LOCK WASHER        | 2           |   |
| 247           | 104002            | 186-260205RA       | 2.6X5 SCREW with Large Washer Ø 7.5          | 1           |   |
| 248           | 104151            | 173-200005R        | 2X5 PHILLIPS SELF TIGHTENING H5 SCREW        | 3           |   |
| 249           | 104149            | 123-063226R        | 2X6 PHILLIPS PAN HEAD SELF TIGHTENING SCREW  | 5           |   |
| 250           | 104147            | 186-170003RA       | 1.7X3 SCREW with Washer                      | 2           |   |
| 251           | 104005            | 186-260006R        | 2.6X6 BINDING FASTENER with LOCK WASHER      | 4           |   |
| 252           | 104009            | 171-260206R        | 2.6X6 BINDING PHILLIPS SELF TIGHTENING SCREW | 16          |   |
| 253           | 104011            | 171-260106R        | 2.6X10 BINDINGPHILLIPS SELF TIGHTENING SCREW | 8           |   |
| 254           | 132681            | 186-000316R        | 2.6X8 BINDING SCREW                          | 2           |   |
| 255           | 104013            | 186-300012R        | 3X12 SCREW with Washer (Small)               | 2           |   |
| 256           | 108973            | 101-063226R        | 2.6X4 PAN HEAD SCREW                         | 1           |   |
| 259           | 095879            | 142-090433R        | 2.5X5X0.3 FLAT WASHER                        | 1           |   |
| 260           | 104880            | 142-090436         | 2.6X5.58X0.5 POLLY VYNAL SLIDER              | 1           |   |
| 261           | 017010            | 142-090430         | 6.2X10.X0.2 POLLY VYNAL SLIDER               | 1           |   |
| 262           | 091518            | 200-100852R        | E-Clip Ø 1.5 SUSTAINER                       | 3           |   |
| 263           | 091517            | 100-100060R        | E-Clip Ø 2.0 SUSTAINER                       | 11          |   |
| 264           | 091516            | 200-100984R        | E-Clip Ø 3.0 SUSTAINER                       | 32          |   |
| 265           | 093074            | 100-100059R        | E-Clip Ø 4.0 SUSTAINER                       | 8           |   |
| 266           | 102294            | 900-100628         | O-RING P6 (#EPDM70)                          | 4           |   |
| 267           | 097663            | 450-300005R        | 1.6X6 PARALLEL PIN                           | 1           |   |
| 268           | 104019            | 200-200304RA       | 1.6X8 PARALLEL PIN SUSTAINER                 | 5           |   |
| 269           | 103021            | 250-100511         | TRANSPORT LATCH SPRING                       | 1           |   |
| 270           | 106069            | 200-100843         | GROUNDING TAB 3                              | 1           |   |
| 271           | 113653            | 900-200055RA       | ICB PEDISTAL                                 | 1           | UBA-10/11/12                            |
| 272           | 112689            | 900-200058RA       | ICB COVER SPONGE                             | 2           | UBA-10/11/12                            |
| 273           | 113654            | 900-200056RA       | ICB COVER                                    | 1           | UBA-10/11/12                            |
| 274           | 104414            | 171-261003R        | 2x4 BINDING PHILLIPS SELF TIGHTENING SCREW   | 1           | UBA-10/11/12                            |
| 275           | 102752            | 900-100846R        | UBA TRANSPORT GUIDE C ASSY.                  | —           | Included with #101, 102, 103, 107 & 108 |
| 276           | 136839            | 900-200238R        | UBA TRANSPORT GUIDE D ASSY.                  | —           | Included with #102, 103, 155 & 156      |
| 277           | 143338            | 900-200203RA       | BAR-SNSR CAP 1                               |             | UBA-10/11/12/14                         |
| 278           | 143339            | 900-200204RA       | DP SNSR-SPR UP 1                             |             | Changed from EDP #102780                |
| 279           | 144684            | 900-200351R        | CN PROTECTION COVER 1                        |             |   |
| 280           | 143598            | 900-200205RA       | CPU WATERPROOF 1                             |             |   |

## UBA Frame Unit Exploded View







Figure 7-6 Frame Unit Exploded View

**UBA Frame Unit Parts List****Table 7-3** Frame Unit Parts List

| <b>Ref №.</b> | <b>EDP Number</b> | <b>JAC Part №.</b> | <b>Description</b>            | <b>Qty.</b> | <b>Remarks</b> |
|---------------|-------------------|--------------------|-------------------------------|-------------|----------------|
| 301           | 102982            | 900-100501R        | UBA TRANSPORT STAND           | 1           |                |
| 302           | 102988            | 900-100594R        | PRISM STAND                   | 1           |                |
| 303           | 106067            | 200-100837R        | STAND GROUNDING TAB           | 1           |                |
| 304           | 102986            | 900-100332R        | UBA STAND GEAR 2              | 2           |                |
| 305           | 103011            | 200-100838R        | STAND GEAR SHAFT              | 2           |                |
| 306           | 052620            | 200-100342R        | STAND GEAR SHAFT              | 1           |                |
| 308           | 052648            | 250-100536         | FRONT GUIDE SPRING            | 1           |                |
| 309           | 108810            | 200-100707R        | UBA STAND GEAR SUSTAINER      | 2           |                |
| 310           | 103012            | 200-100839R        | STAND LEVER SHAFT             | 1           |                |
| 311           | 102987            | 900-100872R        | CASH BOX LEVER                | 2           |                |
| 312           | 052650            | 250-100498R        | FRONT LEVER SPRING            | 2           |                |
| 313           | 102983            | 900-100680R        | CASH BOX LEVER A              | 1           |                |
| 314           | 102984            | 900-100588R        | CASH BOX LEVER B              | 1           |                |
| 315           | 052649            | 250-100011R        | REAR LEVER SPRING             | 1           |                |
| 316           | 128210            | 900-100590         | UBA FRAME A                   | 1           |                |
| 317           | 128212            | 200-100835R        | UBA FRAME B                   | 1           |                |
| 318           | 143211            | 200-100836R        | UBA FRAME BASE                | 1           |                |
| 319           | 104016            | 186-300516R        | 3X6 SCREW with Washer (Small) | 2           |                |
| 320           | 127827            | 200-000332R        | Transport (TR) Stand Bracket  | 1           | UBA-24/25 Only |
| 321           | 127828            | 149-000014R        | 2.6x5 SCREW                   | 2           | UBA-24/25 Only |

**UBA-SS Cash Box Unit Exploded View****Figure 7-7 UBA-SS Standard Cash Box Exploded View (Part 1)**

**UBA-SS Cash Box Unit Exploded View (Continued)****Figure 7-8 UBA-SS Large Cash Box Exploded View (Part 2)**

**UBA Cash Box Pusher Unit Mechanism Exploded View****Figure 7-9 UBA Cash Box Unit Pusher Mechanism Exploded View**

THIS PAGE INTENTIONALLY LEFT BLANK

## Cash Box Unit Parts List

Table 7-4: UBA Cash Box Unit Parts List

| Ref №. | EDP Number | JAC Part №.  | Description                         | Qty. | Remarks                  |
|--------|------------|--------------|-------------------------------------|------|--------------------------|
| 401    | 103176     | 900-101026RA | BUSHING LINK B                      | 2    |                          |
| 402    | 128522     | 900-101027RA | PUSHER PLATE                        | 1    |                          |
| 403    | 081620     | 900-100254R  | O-RING P11 (#EPDM70)                | 8    |                          |
| 404    | 103177     | 900-101028RA | BUSHING LINK A                      | 1    |                          |
| 405    | 070749     | 200-100865   | U-ARM PIN 82                        | 1    |                          |
| 406    | 128523     | 900-101029RA | PUSHER RACK                         | 1    |                          |
| 407    | 128531     | 200-200564R  | PUSHER PI-BEARING                   | 2    |                          |
| 408    | 128524     | 900-101031RA | ROLLER RACK                         | 2    |                          |
| 409    | 104260     | 200-101078RA | LINK SHAFT                          | 2    |                          |
| 410    | 070750     | 200-100864   | LEFT ARM SHAFT 82                   | 1    |                          |
| 411    | 104274     | 250-100559RA | PUSHER SPRING B                     | 1    |                          |
| 412    | 052579     | 900-100583   | RIGHT ROLLER GUIDE R                | 1    |                          |
| 413    | 114533     | 200-200566R  | LEFT ARM SHAFT                      | 1    |                          |
| 414    | 128519     | 200-200567R  | PUSHER BASE                         | 1    |                          |
| 415    | 052626     | 200-100733R  | ROLLER SHAFT GUIDE                  | 1    |                          |
| 416    | 052634     | 200-101010   | PULLEY STUD                         | 2    |                          |
| 417    | 128533     | 900-200352RA | PULLEY S2M W5 B                     | 2    |                          |
| 418    | 128521     | 900-100764R  | PUSHER GUIDE, RIGHT                 | 1    |                          |
| 419    | 128520     | 900-100765R  | PUSHER GUIDE, LEFT                  | 1    |                          |
| 420    | 104615     | 900-100945R  | LABOR ROLLER                        | 2    |                          |
| 421    | 104263     | 200-101079R  | STUD LEVER                          | 2    |                          |
| 422    | 104275     | 250-100539R  | TENSION SPRING LEFT                 | 1    |                          |
| 423    | 104276     | 250-100540R  | TENSION SPRING RIGHT                | 1    |                          |
| 424    | 052561     | 900-100336R  | BUSHING F6B R                       | 1    |                          |
| 425    | 114527     | 250-100560R  | PRESSURE ROLLER SHAFT SPRING, RIGHT | 1    |                          |
| 426    | 114528     | 250-100561R  | PRESSURE ROLLER SHAFT SPRING, LEFT  | 1    |                          |
| 427    | 104268     | 900-100882R  | GEAR (24)                           | 1    |                          |
| 428    | 128518     | 900-100649R  | GEAR, M1-Z16                        | 1    |                          |
| 429    | 104273     | 900-100251R  | GEAR, M1-Z12 (P-1)                  | 1    |                          |
| 430    | 104267     | 900-100972R  | BUSHING                             | 2    |                          |
| 431    | 123525     | 900-200353R  | BOX TRANSPORT GEAR 3RD              | 1    |                          |
| 432    | 103167     | 900-100676R  | ROLLER COVER                        | 1    |                          |
| 433    | 128529     | 900-200354R  | LINK ROLLER 2                       | 2    |                          |
| 434    | 104256     | 200-101080R  | GEAR PUSHER SHAFT                   | 1    |                          |
| 435    | 052563     | 900-100581R  | RACK GEAR R                         | 1    |                          |
| 436    | 128528     | 900-200226R  | STS TIMING BELT                     | 2    | Recommended Service Part |
| 437    | 104258     | 200-101003R  | ROLLER SHAFT                        | 1    |                          |
| 438    | 026108     | 900-100392R  | ROLLER R (RE-7V10)                  | 4    |                          |
| 439    | 034851     | 900-100294R  | ROLLER (REO-06)                     | 4    |                          |
| 440    | 052562     | 900-100580R  | B OL PULLEY R                       | 2    |                          |

**Table 7-4: UBA Cash Box Unit Parts List (Continued)**

| <b>Ref №.</b> | <b>EDP Number</b> | <b>JAC Part №.</b> | <b>Description</b>  | <b>Qty.</b> | <b>Remarks</b>           |
|---------------|-------------------|--------------------|---|-------------|--------------------------|
| 441           | 128532            | 900-200355R        | PULLEY S2M W5 A R   | 2           |                          |
| 442           | 034849            | 200-100552R        | PULLEY R (REO-04)   | 2           |                          |
| 443           | 123647            | 200-100893R        | TRANSPORT PULLEY SHAFT  | 1           |                          |
| 444           | 052577            | 900-100582R        | PULLEY COLLAR R   | 1           |                          |
| 445           | 103175            | 900-100595R        | PULLEY COVER  | 1           |                          |
| 446           | 003705            | 100-100092R        | E-RING Ø2 SUSTAINER   | 22          |                          |
| 447           | 003707            | 100-100043R        | E-RING Ø3 SUSTAINER   | 6           |                          |
| 448           | 003708            | 100-100044R        | E-RING Ø4 SUSTAINER   | 8           |                          |
| 449           | 005555            | 186-260106R        | 2.6X6 PAN HEAD SCREW with Spring and Flat Washer              | 4           |                          |
| 450           | 119247            | 183-250005R        | 2.3X5 PHILLIPS SELF TIGHTENING PAN HEAD SCREW and Flat Washer | 2           |                          |
| 451           | 104280            | 186-260012RA       | 2.6X12 SCREW with Spring and Flat Washer (Small)              | 2           |                          |
| 452           | 081191            | 200-100997R        | 2X10 PARALLEL PIN SUSTAINER                                   | 6           |                          |
| 453           | 104616            | 200-101081RA       | ROLLER STUD   | 2           |                          |
| 454           | 104266            | 900-101033RA       | TENSION LEVER ROLLER  | 2           |                          |
| 455           | 103165            | 900-101034RA       | TRANSPORT SHAFT BUSHING                                       | 1           |                          |
| 456           | 106593            | 900-101035RA       | STW-FT60 TO.25 POLYVYNAL SLIDER                               | 2           |                          |
| 457           | 123914            | 200-000333R        | 1X5 PARALLEL PIN SUSTAINER                                    | 1           |                          |
| 458           | 123526            | 900-200356R        | BOX TRANSPORT GEAR 2ND  | 1           |                          |
| 461           | 123527            | 900-200053RA       | BOX TRANSPORT GEAR 1ST  | 1           |                          |
| 463           | 128526            | 200-200570R        | GEAR STUD (P-2)   | 1           |                          |
| 464           | 003611            | 181-308000R        | M3X8 PAN HEAD SCREW with Spring and Flat Washer               | 2           |                          |
| 465           | 103159            | 200-101083RA       | LEVER CASE  | 4           |                          |
| 466           | 070751            | 200-101084RA       | STOP LEVER PIN  | 4           |                          |
| 467           | 070742            | 900-100683R        | STOP LEVER R  | 4           |                          |
| 468           | 070720            | 250-100562RA       | STOP LEVER SPING  | 4           |                          |
| 469           | 041901            | 171-200108RA       | M2X8 PHILLIPS SELF TIGHTENING SCREW, CHROME                   | 4           |                          |
| 470           | 127280            | 900-101037RA       | CASH BOX STACKER  | 1           |                          |
| 471           | 034869            | 250-100047R        | LB-02-C BACKUP PLATE SPRING                                   | 2           |                          |
| 472           | 103173            | 900-100762R        | RECEIVER PLATE  | 1           |                          |
| 473           | 131607            | 200-100996R        | LOCKING PLATE   | 1           |                          |
| 474           | 108826            | 100-350000R        | 3X5 PHILLIPS SELF TIGHTENING SCREW with Washer                | 2           |                          |
| 475           | 127281            | 900-100609R        | CASH BOX OPENING COVER  | 1           |                          |
| 476           | 104259            | 200-101086RA       | FULCRUM SHAFT (1)   | 1           |                          |
| 477           | 104290            | 900-100158R        | HANDLE  | 1           | For Standard Cash Box    |
|               | 121968            | 900-200661RA       | HANDLE (RED)  | 1           | For Standard Cash Box    |
| 478           | 106537            | 900-100489R        | HANDLE (ICB)  | 1           | For Intelligent Cash Box |
|               | 121969            | 900-200062RA       | HANDLE (ICB) (RED)  | 1           | For Intelligent Cash Box |


**Table 7-4: UBA Cash Box Unit Parts List (Continued)**

| <b>Ref №.</b> | <b>EDP Number</b> | <b>JAC Part №.</b> | <b>Description</b>                            | <b>Qty.</b> | <b>Remarks</b>            |
|---------------|-------------------|--------------------|---|-------------|---------------------------|
| 479           | 103171            | 900-100241R        | CAP HANDLE                                    | 2           |                           |
| 480           | 115909            | 171-300014R        | 3X10 PHILLIPS SELF TIGHTENING PAN HEAD SCREW  | 4           |                           |
| 481           | 104278            | 950-100151RA       | CASH BOX LABEL                                | 2           |                           |
| 482           | 103170            | 900-100495R        | INTELLIGENT CASH BOX                          | 1           | For Intelligent Cash Box  |
| 483           | 103169            | 900-100494R        | INTELLIGENT BOX COVER                         | 1           | For Intelligent Cash Box  |
| 484           | 105875            | 300-100607RA       | INTELLIGENT CIRCUIT BOARD                     | 1           | Recommended Service Parts |
| 485           | 049531            | 171-260008R        | 2.6X8 PHILLIPS PAN HEAD SELF TIGHTENING SCREW | 2           |                           |
| 486           | 113227            | 200-200267R        | INTELLIGENT FRAME ASSY                        | 1           | For Intelligent Cash Box  |
| 487           | 113207            | 900-101053RA       | CAP   | 2           |                           |
| 488           | 128525            | 200-101064RA       | GEAR STUD                                     | 1           |                           |
| 489           | 125445            | 173-230005R        | M2.6X5 FLAT HEAD PLATE SCREW (Small)          | 2           |                           |
| 491           | 113228            | 900-101054RA       | CUSHION, INTELLIGENT                          | 1           | For Intelligent Cash Box  |
| 492           | 110029            | 149-000015R        | SCREW GUIDE                                   | 1           |                           |
| 493           | 110080            | 250-100563RA       | NIPPLE SPRING                                 | 1           |                           |
| 494           | 109917            | 200-101100RA       | NIPPLE PIN                                    | 1           |                           |
| 495           | 109916            | 200-101101RA       | SOCKET GUIDE                                  | 1           |                           |
| 496           | 113235            | 200-101102RA       | FULCRUM SHAFT (2)                             | 1           |                           |
| 497           | 128669            | 900-100422R        | UBA-SS CASH BOX PUSHER MECHNISM MP6           | 1           |                           |
| 498           | 113208            | 900-101041RA       | T3 BUSHING                                    | 1           |                           |
| 499           | 003718            | 100-100046R        | CLAMP (#5103-18 4Ø)                           | 2           |                           |
| 500           | 121843            | 700-000179R        | UBA INTELLIGENT CASH BOX KIT                  | —           |                           |
| 501           | 104265            | 900-101030RA       | ROLLER ARM                                    | 2           |                           |
| 504           | 127705            | 900-200357R        | IQ P- BOX                                     | 1           |                           |
| 505           | 127709            | 900-200358R        | IQ P-BOX DOOR                                 | 1           |                           |
| 506           | 127710            | 900-200359R        | IQ P-BOX ICB COVER                            | 1           |                           |
| 507           | 127711            | 900-200360R        | IQ P-BOX HANDLE                               | 1           |                           |
| 508           | 127712            | 900-200361R        | IQ P-BOX HANDLE BRA                           | 1           |                           |
| 509           | 127713            | 900-200237R        | IQ P-BOX RE PLATE                             | 1           |                           |
| 510           | 127706            | 900-200362R        | TANG CATCH UBA                                | 1           |                           |
| 511           | 127707            | 200-200770R        | NIPPLE SOCKET                                 | 1           |                           |
| 512           | 127708            | 200-200771R        | NIPPLE PIN                                    | 1           |                           |
| 513           | 127714            | 250-100678R        | IQ P-BOX SPRING                               | 2           |                           |
| 514           | 127715            | 250-100679R        | NIPPLE SPRING 2                               | 1           |                           |
| 515           | 127716            | 900-200363R        | BATTERY SPONGE                                | 1           |                           |
| 516           | 076466            | 171-200041R        | 2X4 BINDING PHILLIPS SELF TIGHTENING SCREW    | 2           |                           |
| 517           | 128220            | 300-100436RA       | ICB CIRCUIT BOARD                             | 1           | Recommended Service Parts |
|               | 139237            | 200-101140R        | REFLECTOR (Standard Cash Box)                 | 1           | Recommended Service Parts |

**Table 7-4: UBA Cash Box Unit Parts List (Continued)**

| <b>Ref №.</b> | <b>EDP Number</b> | <b>JAC Part №.</b> | <b>Description</b>                         | <b>Qty.</b> | <b>Remarks</b>            |
|---------------|-------------------|--------------------|--|-------------|---------------------------|
| 518           | 128230            | 451-100104RA       | BATTERY (CR2450HR T-4 WK)                  | 1           | Recommended Service Parts |
|               | 139239            | 900-200365R        | PROTECTION SPONGE (Standard Cash Box)      | 1           | Recommended Service Parts |
| 519           | 101172            | 172-100002R        | 2X6 BINDING PHILLIPS SELF TIGHTENING SCREW | 5           |                           |
| 520           | 130307            | 950-171023R        | LEFT BOX LABEL                             | 2           |                           |
| 521           | 188191            | 701-000211R        | Kit, UBA CASH BOX DOOR (500 Note)          | 1           |                           |

## Face Unit Exploded View



**Figure 7-10 Face Unit Exploded View**

## Faceplate Unit Parts List

**Table 7-5 Face Unit Parts List**

| Ref N°. | EDP Number | JAC Part N°. | Description                                  | Qty. | Remarks                          |
|---------|------------|--------------|--|------|----------------------------------|
| 601     | 113236     | 400-100586RA | RIGHT FACEPLATE HARNESS PLATE                | 1    |                                  |
| 602     | 113237     | 400-100587RA | RIGHT FACEPLATE RELAY HARNESS R              | 1    | For UBA<br>FACEPLATE UNIT<br>A   |
| 603     | 006481     | 186-300016R  | 3X16 SCREW with Spring and Flat Washer       | 2    |                                  |
| 604     | 056771     | 200-200332RA | SHIELD PLATE                                 | 1    |                                  |
| 605     | 113927     | 200-101088RA | SHIELD PLATE                                 | 1    | For UBA<br>FACEPLATE UNIT<br>A   |
| 606     | 113928     | 200-101084RA | WIRE HOLDER                                  | 1    | For UBA<br>FACEPLATE UNIT<br>A   |
| 607     | 112644     | 900-200366R  | INSERT LIGHT GUIDE                           | 2    |                                  |
| 608     | 113926     | 900-101043RA | INSERT GUIDE UBA (BLACK)                     | 1    | For UBA<br>FACEPLATE UNIT<br>A/2 |
|         | 112642     | 900-101044RA | INSERT GUIDE UBA                             | 1    | For UBA<br>FACEPLATE UNIT<br>1   |
| 609     | 056165     | 172-261003R  | 2.6X8 BINDING PHILLIPS SELF TIGHTENING SCREW | 1    |                                  |
| 610     | 112880     | 300-100430RA | LED CIRCUIT BOARD                            | 1    |                                  |
|         | 112874     | 300-100431RA | LED CIRCUIT BOARD                            | 1    |                                  |
| 611     | 112903     | 300-100432RA | LED CIRCUIT BOARD                            | 1    |                                  |

## Optional Unit Parts List

**Table 7-6 Optional Unit Parts List**

| Ref N°. | EDP Number | JAC Part N°. | Description   | Qty. | Remarks      |
|---------|------------|--------------|---|------|--------------|
| OP101   | 123467     | 300-500007R  | 24VDC/13.5VDC Circuit Board plus RS-232C Signal Level Conversion Board  | 1    |              |
|         | 123523     | 300-200139R  | RS-232C Signal Level Conversion Board                                   |      | UBA-14       |
|         | 136243     | 300-200140R  | cc Talk Interface Conversion Board                                      |      |              |
|         | 133297     | 300-100398R  | 24VDC/13.5VDC Circuit Board USB Interface Conversion Board              |      | UBA-14       |
| OP-102  | 124736     | 400-100556RA | RS-232C Interface Harness with M3x12W Washer Sems Screw and Clamp       | 1    | UBA 10/11/12 |
|         | 124738     | 400-000084R  | Photo-Coupler Interface Harness with M3x12W Washer Sems Screw and Clamp |      | UBA 10/11/12 |
|         | 122468     | 701-100094R  | RS-232C Interface Harness with M3x12W Washer Sems Screw and Clamp       |      | UBA-14       |
|         | 122469     | 701-100095R  | Photo-Coupler Interface Harness with M3x12W Washer Sems Screw and Clamp |      | UBA-14       |
| OP-103  | 13605      | 400-100616R  | cc Talk Interface Harness with M3d2W Washer Sems Screw and Clamp        | 1    |              |
|         | 137900     | 701-100096R  | USB Interface Harness with M3x12W Washer Sems Screw and Clamp           |      |              |
| OP-104  | 134358     | 400-100615R  | 24VDC Power Harness   | 1    |              |
|         | 134357     | 400-100614R  | 12VDC Power Harness   |      |              |
| OP-105  | 146357     |              | RS232C Interface Harness  | 1    |              |
| OP-106  | 063250     | 171-504033R  | M2.6x6 Binding. Self Tightening Phillips Screw                          | 2    |              |

THIS PAGE INTENTIONALLY LEFT BLANK

# UBA® Series

## Universal Bill Acceptor (UBA-1x-SS & UBA-x4-SS/SU)

### Section 8

#### 8 INDEX

##### B

- Banknote Jam  
clearing a... 2-10
- Banknote Retrieval  
methods for... 2-9
- Bill Acceptor  
general information describing a... 1-1
- BNF Motor  
removal/replacement of... 4-6

##### C

- Calibration  
procedures for... 6-4
- Cautions  
inventory stock enduring high temperature, high humidity or dust... 1-2
- Circuit Board  
Removal/Replacement... 4-3
- Cleaning  
lenses  
methods of... 2-11
- methods of and equipment required for... 1-3
- paths, rollers & belts... 2-11
- solvent use warning... 2-11
- Closing units  
instructions for... 1-2
- Component Parts  
system & individual primary... 5-1
- Configurations  
related jumper positions for... 2-9
- Contact Information  
Address and Telephone Numbers for... 1-17

##### D

- Dimensions  
of a UBA x4-SS Unit... 1-11; 1-12; 1-13; 1-14
- 3 view drawings of... 1-8
- DIP Switch Block  
front panel  
location of... 2-2
- DIP Switch Settings  
troubleshooting of... A-1
- Disassembly/Reassembly  
instructions for... 4-1
- disassembly/reassembly of... 4-6; 4-7

##### E

- Exploded views  
illustrations of... 7-1
- External Power Supply  
Part No. for... 6-4

##### F

- Faults  
table listings of... A-1
- Flowchart  
Operational Flow... 2-17
- Front Panel Indicators  
location of... 2-1

##### I

- Installation  
steps for... 2-1

##### J

- Jam warning  
bill insertion  
damaged, worn, shuffling... 1-3
- JCM Contact Information  
Address and Telephone Numbers for... 1-17

##### L

- Lower Sensor Board  
within Validator  
removal/replacement of... 4-9

##### M

- Mag Head Test Board  
Part No. for... 6-5
- Mounting holes  
location of... 2-1
- M4 Screw  
maximum length of... 2-1

##### N

- Navigation  
within manual  
procedure for... 1-1

##### P

- Performance Testing  
instructions for... 6-1
- Performance Tests  
9 steps of... A-5
- Pin Assignments  
Front Panel Bezel Connector assignments... 2-6
- Optional cc-Talk Connector assignments... 2-9
- Rear Panel Connector assignments... 2-3
- Precaution Symbols  
types of... 1-2
- Preventive Maintenance  
cleaning materials required... 2-11
- Primary Features  
of UBA Series... 1-6
- Product Parts Lists  
tables of... 7-1

**R**

Red Chip LED  
location of the... 2-1  
Reference Paper  
Black  
Part No. for... 6-4  
Ultra Violet  
Part Number for... 6-4  
White  
Part No. for... 6-4  
removal/replacement... 4-9

**S**

Safety  
pictographs indicating... 1-1  
Schematic  
circuit flow  
interface... 2-12; 2-13; 2-14  
Security Locks  
installation of... 2-2  
Special Notes  
*italic* text highlights... 1-1  
Specifications  
electrical... 1-5  
model number... 1-2  
structural... 1-5  
technical... 1-5  
Steps  
sequential numbering of... 1-1  
Symbol definitions  
3 types of... 1-2

**T**

Timing Belt  
Transport C... 4-9  
Timing Belts  
Final removal/replacement... 4-12  
TITO  
definition of... 2-2  
Tool Requirements  
for calibrating unit... 6-4  
workbench & field... 6-1  
Transport Unit  
Guides B & C... 4-6; 4-7

**U**

Universal Bill Acceptor  
photo of a... 1-1

**W**

Warning  
dropping or throwing of unit... 1-2  
holding Transport Upper Guide Open when removing  
covers... 4-2  
liquid damage... 1-3  
solvent use... 2-11  
Wiring Diagrams  
system & individual primary parts of... 5-1

# UBA® Series

## Universal Bill Acceptor (UBA-1x-SS & x4-SS-SU)

### Appendix A

#### A TROUBLESHOOTING

This section provides Troubleshooting instructions for the Universal Bill Acceptor Series (UBA). This section contains the following information:

- Introduction
- Troubleshooting Overview
- Fault Table Listings
- Performance Tests
- LED Diagnostic Codes

#### Introduction

Most Bill Acceptor failures are due to minor causes. Before replacing any parts, make sure that all assembly and circuit board connectors are properly fitted and the harness is properly connected.

Faulty bill acceptance by the Bill Acceptor is often caused when dust or iron powder adheres to the identification sensor, magnetic sensor or Transport belt. Clean the acceptor section first, then observe the operating state of acceptor in detail when initializing power. This observation is important in locating any failure causes and the possible fault point. If the acceptor head has to be repaired by

disassembling it, always recalibrate the sensors following a repair.

Perform all repairs by referring to the Calibration and Flash Memory Software Downloading section in the “Adjustment Procedure” on page 6-5 of Section 6, and in the Disassembly/Reassembly area of Section 4 in this Service Manual.

#### Troubleshooting Overview

The UBA allows the operator to perform fault diagnosis by checking various fault table listings against the symptom and survey the cause(s) of any failure occurrences during the process.

After determining the cause of the failure, execute the Performance Test, perform a sensor readjustment and then repair the UBA Unit replacing any appropriate parts deemed necessary.

#### Fault Table Listings

Table A-1 through Table A-3 list the various possible UBA fault conditions that can occur and the necessary actions required to correct them.

**Table A-1** General Fault Conditions

| Symptoms/Error Messages                                      | Possible Fault Causes  | Corrective Action Required   |
|--|--|--|
| Bill Acceptor is not working<br>(does not accept any bills). | No external power is applied to the Bill Acceptor (+12VDC & GND) | Verify that the Power Supply +12VDC and Ground cables are connected to the appropriate pins on the main connector. NOTE: The small LED to the left of the front panel DIP Switches indicates power available when lit.             |
|  | Wrong or inappropriate connections                               | Verify that all harness connectors are properly seated. Check for any bent, missing or damaged pins in the connector plugs and mating receptacles.   |
|  | Corrupted software.  | Redownload the correct software. Refer to “Software Downloading Procedure” on page 6-2 of Section 6 for software downloading instructions.   |
|  | CPU Board failure.   | Refer to the “Performance Tests” on page A-5 of this Appendix and conduct an Initial Operation Test. If the test result is Negative (NG), replace the CPU Board. Make sure to recalibrate the sensors after CPU Board is replaced. |
|  | ICB Sensor Board is not inserted into the CPU Board socket.      | Remove and then reinsert the ICB Sensor Board into the CPU Board socket.<br>NOTE: The ICB Sensor Board must be inserted in place regardless if its features are being used or not.   |
|  | (For UBA-11 only)<br>The EPROM is inserted backwards.            | Remove the Acceptor Unit from the frame.<br>Remove the EPROM from CPU Board and reinsert it in the correct direction.  |

**Table A-1 General Fault Conditions (Continued)**

| Symptoms/Error Messages        | Possible Fault Causes   | Corrective Action Required   |
|--------------------------------|---|--|
| Bill jams occur often.         | Drive belts are dirty or damaged.   | Clean all drive belts and pressure rollers. Replace as necessary.  |
|                                | A pressure roller spring is loose or missing.   | Check all pressure roller springs using a finger press test. Replace as necessary.   |
|                                | A foreign object is lodged in the Transport path and/or inside the Cash Box.  | Clean the Transport path and remove any foreign object discovered.   |
|                                | The Acceptor Unit is not properly seated all the way into the frame (the Acceptor Unit latch release levers are not locked onto the frame). | Re-seat the Acceptor Unit back into the frame so it is firmly seated all the way back into the frame so the Acceptor Unit release lever latches securely lock onto the frame.                                |
|                                | Bill is wider than 85 mm or narrower than 62mm (out of UBA Bill width specifications).  | Use only bills widths having the correct UBA size specifications.  |
| Acceptance rates.              | Dirt and/or stains on the rollers, belts and lenses.  | Clean the Transport path. Refer to the Cleaning/Preventive Maintenance procedure in Section 2 of this Manual.  |
|                                | The unit has been dis-assembled and re-calibration adjustment has not occurred following a reassembly.                                      | Make sure to readjust the sensors after reassembling the UBA Unit. Refer to the "Forced Download Requirements" on page 6-4 of Section 6 of this Manual.  |
|                                | The wrong software or an old version of the software being used.  | Make sure that the programmed Flash or EPROM memory software is the latest version, and it supports the currency values and country allowing acceptance.   |
|                                | Software not designed to accept current Bills   | Check the particular specifications for the required Bill type acceptance, and make sure the bills will be accepted by the software loaded (i.e., check denomination/issuing year, etc.).                    |
|                                | Sensor lenses are loose or missing.   | Sensor lenses require re-positioning. Contact JCM Technical Support.   |
| Upper Guide can not be opened. | Centering Guides are not at their home position.  | Turn the Power OFF and ON again. This action should tell the host machine to send a reset command to reinitialize the unit.  |
|                                |   | If power cannot be applied, use a Hexagonal Nut Driver to open the Upper Guide and manually reset the guide.   |
| All bills being rejected.      | Incorrect software (different currency type).   | Download the correct software for currency being accepted. Refer to "Software Downloading Procedure" on page 6-2 of Section 6 of this Manual regarding Software Downloading.                                 |
|                                | Bills are not being accepted by the software.   | Make sure the bill values required are included in the software specifications (i.e., denominations/issuing year, etc.) Refer to the "Forced Download Requirements" on page 6-4 of Section 6 of this Manual. |
|                                | Incorrect DIP Switch settings.  | Enable all denominations by setting all DIP switches to OFF.   |
|                                | Bill acceptance is being inhibited by Host Controller command   | Enable Bill acceptance for the required Host command.  |
|                                | Upper/Lower Sensor Board failure.   | Change the Upper or Lower Sensor Board with a known good board. Refer to Section 4 regarding Circuit Board Removal.  |
|                                | Unit was disassembled and re-calibration did not occur following reassembly.  | Recalibrate all UBA Sensors following reassembly.  |

**Table A-1 General Fault Conditions (Continued)**

| <b>Symptoms/Error Messages</b> | <b>Possible Fault Causes</b>                                      | <b>Corrective Action Required</b>   |
|--------------------------------|---|---|
| Motor continues to run.        | Upper Guide is open.  | Firmly close the guide.   |
|                                | A foreign object or a jammed bill is stuck in the Transport path. | Open the Guide, remove the foreign object or jammed bill, and close the cover.  |
|                                | Motor driver failure.   | Refer to the "No. 1 Transport Motor Forward/Reverse Rotation Test" on page A-5 of this Appendix and conduct a Forward/Reverse Motor Rotation Test.        |
| Can not enter the TEST mode.   | Incorrect DIP Switch settings.                                    | Set the DIP Switch No. 8 to ON, and resupply power to the UBA.  |
|                                | Dip switch failure.   | Refer to the "No. 9 DIP Switch Test" on page A-11 of this Appendix and conduct a DIP Switch TEST to check if the specific DIP Switch Block has a failure. |
|                                | CPU Board failure.  | Exchange the CPU Board with a known good board. Refer to "CPU Board Removal" on page 4-3 of Section 4 of this Manual regarding Circuit Board Removal.     |

**Table A-2 Adjustment Fault Conditions**

| <b>Symptoms/Error Messages</b>   | <b>Possible Fault Causes</b>                | <b>Corrective Action Required</b>  |
|--|---|--|
| Can not start the ADJTOOL_V***.exe program by double-clicking on its icon. | PC Operating System (OS) is not compatible. | The current Adjustment program only supports the Windows 2000/XP Operating System.   |
|  | The program files are corrupted.            | Request the correct programs from JCM.   |
| Communication Error.   | Wrong or inappropriate connections          | Check the PC harness connections and the related UBA interface connectors. Check for any bent, missing or damaged pins in the connector plug and receptacle. |
|  | UBA DIP Switch settings are incorrect.      | Set the UBA DIP Switches 1 to 7 OFF and Switch 8 to ON. Recycle the power supplied to the external maintenance power supply (P/N 702-000148).                |
|  | DIP Switch failure.                         | Refer to the "No. 9 DIP Switch Test" on page A-11 of this Appendix and conduct a DIP Switch Test.  |
|  | CPU Board failure.                          | Exchange the CPU Board with a known good one. Refer to Section 4 regarding Circuit Board Removal.  |
| Adjustment Error.  | Incorrect reference paper type.             | Follow the instruction provided in the ADJTOOL_V***.exe program and use the correct reference paper recommended.   |
|  | Upper/Lower Sensor Board failure.           | Change the Upper or Lower Sensor Board with a known good board. Refer to Section 4 regarding Circuit Board Removal.  |

**Table A-3** Communication Fault Conditions

| Symptoms/Error Messages       | Possible Fault Causes                    | Corrective Action Required  |
|-------------------------------|--|---|
| Cannot communicate with host. | DIP Switch settings are incorrect.       | Set all DIP Switches to OFF.  |
|                               | Connectors are off or loosely connected. | Firmly reconnect all of the communication connectors.   |
|                               | Damaged connector pins.                  | Check for any bent, missing or damaged pins in the connector plugs and mating receptacles.  |
|                               | CPU Board is corrupted.                  | Exchange the CPU Board with a known good one. Refer to "Circuit Board Removal" on page 4-3 of Section 4 of this Manual regarding Circuit Board Removal.   |
|                               | Incorrect Interface.                     | Verify that the correct interface between the Host machine and the Bill Acceptor is being used.   |
|                               | Acceptor Head Failure.                   | The ICB Board is not installed on the CPU Board.<br>Install the ICB Board.<br><br>The ICB Board is installed incorrectly. Check that the PLUG Number on the ICB Board and SOCKET Number on the CPU Board agree. Reinstall the ICB Board in the correct direction. |

## Performance Tests

The UBA is equipped with diagnostic features to aid in repair and maintenance. This portion of Appendix A describes the test procedure for use with each function using DIP Switch settings to identify the cause of a failure condition. In order to identify a failure condition's cause, the UBA has to be in the TEST mode.

To enter the TEST mode perform the following steps:

1. Set DIP Switch No. 8 to ON and supply the power to the UBA.
2. Check that both the Red and Green diagnostic LEDs are lit. This condition indicates the unit is now in the TEST mode.
3. Set the DIP Switches depending on the test you wish to execute.
4. Set DIP Switch No. 8 to OFF to start a particular test. When the test begins, both the Red and Green diagnostic LEDs will extin-

guish (go out) After few seconds, the diagnostic LEDs will independently turn ON & OFF depending on the test being executed.

5. To finish a test, set DIP Switch No. 8 to ON again, and turn the UBA power OFF.

## Choosing and Selecting Operational Tests

Set the UBA into the "Test Mode", and then set the DIP Switches to match each operational test shown in the following Test Tables. Set DIP Switch 8 to OFF initially to start each test.



*NOTE: The setting of DIP Switch 8 to ON again will interrupt a test, and restore the system to the Test Mode.*

### No. 1 Transport Motor Forward/Reverse Rotation Test

The tests listed in Table A-4 detect the forward and reverse rotational motor speed. Confirm that the motor operates smoothly without emitting abnormal noise.

**Table A-4 Transport Motor Speed Test Error Conditions**

| <b>DIP Switch Block Settings</b> |                       |                         |  |
|----------------------------------|-----------------------|-------------------------|--|
| <b>Motor Speed Condition</b>     | <b>Red LED Status</b> | <b>Green LED Status</b> | <b>Causes and Conditions</b>   |
| Normal                           | OFF                   | ON                      | Normally runs and stops when cycled.   |
| Fast                             | 2 Flashes             | OFF                     | Contact JCM Technical Support  |
| Slow                             | 3 Flashes             | OFF                     | The Transport Motor Speed Encoder Sensor does not detect motor rotation. Check that all harness connectors are seated. A Motor or CPU Board failure may have occurred. Exchange the Motor/CPU Board with a known good board. Refer to Section 4 regarding Circuit Board Removal. |



If diagnostic LED status is different from the Table A-4 listed states, contact JCM Technical Support.

### No. 2 Stacker Test

The tests listed in Table A-5 detect the Bill Stacker's operational condition. When the test starts, the pushing mechanism will begin operating constantly.

When the Green LED lights, it indicates the Stacker is working properly.

If the Red LED flashes, refer to the Stacker Test Error Conditions listed in Table A-5 to discover the probable error condition.

**Table A-5 Bill Stacker Test Error Conditions**

| DIP Switch Block Settings |                |                  |   |
|---------------------------|----------------|------------------|---|
| Stacker Condition         | Red LED Status | Green LED Status | Causes and Conditions   |
| Stacker Full              | 1 Flash        | OFF              | A Stacker Encoder Board failure may have occurred. Check all harnesses and connectors. Exchange the Stacker Encoder Board and/or CPU Board if required with a known good board. Refer to Section 4 regarding Circuit Board Removal.   |
| Stacker Jam               | 2 Flashes      | OFF              | An Exit Sensor Board failure may have occurred. Check all harnesses and connectors. Exchange the Exit Sensor Board and/or CPU Board if required with a known good board. Refer to Section 4 regarding Circuit Board Removal.  |
| Stacker Motor Lock        | 4 Flashes      | OFF              | Stacker motor may be defective. Change the motor if defective. A Stacker Encoder Board failure may have also occurred. Check all harnesses and connectors. Exchange the Stacker Encoder Board and/or CPU Board if required with a known good board. Refer to Section 4 regarding Circuit Board Removal. |
| Cash Box Error            | 10 Flashes     | OFF              | A Cash Box Sensor Board failure may have occurred. Check all harness and connectors. Change the Box Sensor Board and/or CPU Board if required with a known good board. Refer to Section 4 regarding Circuit Board Removal.  |



If diagnostic LED status is different from the Table A-5 listed states, contact JCM Technical Support.

### No. 3 Running Test

The tests listed in Table A-6 detect the UBA's operational condition. When the test starts, the following operation is continuously repeated.

If neither the Red or Green LED lights, it means the UBA is operating properly.

If the Red LED flashes, refer to Running Test Error Conditions listed in Table A-6 to discover the probable error condition.

**Table A-6 UBA Running Test Error Conditions**

| DIP Switch Block Settings |                |                  |   |
|---------------------------|----------------|------------------|---|
| UBA Condition             | Red LED Status | Green LED Status | Causes and Conditions   |
| Stacker Full              | 1 Flash        | OFF              | A Stacker Encoder Board failure may have occurred. Check all harnesses and connectors. Exchange the Stacker Encoder Board and/or CPU Board if required with a known good board. Refer to Section 4 regarding Circuit Board Removal. |
| Stacker Jam               | 2 Flashes      | OFF              | An Exit Sensor Board failure may have occurred. Check all harnesses and connectors. Exchange the Exit Sensor Board and/or CPU Board if required with a known good board. Refer to Section 4 regarding Circuit Board Removal.        |

**Table A-6 UBA Running Test Error Conditions (Continued)****DIP Switch Block Settings**

| UBA Condition             | Red LED Status | Green LED Status | Causes and Conditions   |
|---------------------------|----------------|------------------|---|
| Acceptor Jam              | 4 Flashes      | OFF              | Check the prisms for dirt or scratches. To clean the prisms, refer to Section 2 regarding Preventive Maintenance. A Lower Sensor Board failure may have occurred. To change the Lower Sensor Board refer to Section 4 regarding Circuit Board Removal.  |
| Motor Lock-up             | 6 Flashes      | OFF              | The Transport Motor Speed Encoder Sensor does not detect motor rotation. Check all harnesses and connectors. A Motor or CPU Board failure may have occurred. Exchange the Motor and/or CPU Board with a known good motor or board. Refer to Section 4 regarding Disassembly Instructions and Circuit Board Removal. |
| Upper PCB Set-up Error    | 7 Flashes      | OFF              | An Upper Sensor Board failure may have occurred. To Exchange the Upper Sensor Board with a known good board. Refer to Section 4 regarding Circuit Board Removal.  |
| Anti-Pullback Unit Error  | 9 Flashes      | OFF              | An Anti-Pullback Home Sensor Board and/or a Lower Sensor Board failure may have occurred. Check all harnesses and connectors. Exchange the Anti-Pullback Home Sensor Board and/or a Lower Sensor Board with a known good board. Refer to Section 4 regarding Circuit Board Removal.                                 |
| Cash Box Error            | 10 Flashes     | OFF              | A Cash Box Sensor Board failure may have occurred. Check all harness and connectors. Exchange the Cash Box Sensor Board and/or CPU Board if required with a known good board. Refer to Section 4 regarding Circuit Board Removal.   |
| Solenoid Error            | 13 Flashes     | OFF              | A Solenoid or an Upper Sensor Board failure may have occurred. Check all harness and connectors. Exchange the Upper Sensor Board with a known good board. Refer to Section 4 regarding Disassembly Instructions and/or Circuit Board Removal.   |
| Centering Mechanism Error | 14 Flashes*    | OFF              | Centering mechanism Home Sensor Board and/or CPU Board failure may have occurred. Check all harnesses and connectors. Exchange the Centering Mechanism Home Sensor Board with a known good board. Refer to Section 4 regarding Circuit Board Removal.   |

\*. NOTE: If the Centering Mechanism's Home Sensor is blocked or disabled, the UBA will not error during this test. The Centering Mechanism will just perform a short cycle and continue to operate.



If diagnostic LED status is different from the Table A-6 listed states, contact JCM Technical Support.

#### No. 4 Anti-Pullback Mechanism Test


The test listed in Table A-7 detects the Anti-Pullback mechanism operational condition.

When the Green and Red LEDs are out, it indicates the Anti-Pullback mechanism is working properly.

The Green LED will Flash as the Anti-Pullback Mechanism passes the Home Position.

If there are any problems with the centering mechanism, the Red LED will blink 9 times.

**Table A-7** Anti-pullback Mechanism Test Error Conditions



| Anti-Pullback Mechanism Condition | Red LED Status | Green LED Status | Causes and Conditions   |
|-----------------------------------|----------------|------------------|---|
| Anti-Pullback Unit Error          | 9 Flashes      | OFF              | An Anti-Pullback Home Sensor Board and/or a Lower Sensor Board failure may have occurred. Check all harnesses and connectors. Exchange the Anti-Pullback Home Sensor Board and/or a Lower Sensor Board with a known good board. Refer to Section 4 regarding Circuit Board Removal. |



If diagnostic LED status is different from the Table A-7 listed states, contact JCM Technical Support.

#### No. 5 Centering Mechanism Test


The test listed in Table A-8 detects the Centering Mechanism operational condition.

When the Centering Mechanism is in the Home Position, the Green LED will be steady ON.

When the Green and Red LEDs are out, it indicates the Centering Mechanism is working properly.

If there are any problems with the Centering Mechanism Sensor Board, the Red LED will blink 14 times.

**Table A-8** Centering Mechanism Test Error Conditions



| Centering Mechanism Condition | Red LED Status | Green LED Status | Causes and Conditions   |
|-------------------------------|----------------|------------------|---|
| Centering Mechanism Error     | 14 Flashes     | OFF              | Centering Mechanism Home Sensor Board and/or CPU Board failure may have occurred. Check all harnesses and connectors. Exchange the Centering mechanism Home Sensor Board with a known good board. Refer to Section 4 regarding Circuit Board Removal. |



If diagnostic LED status is different from the Table A-8 listed states, contact JCM Technical Support.

## No. 6 Solenoid Test

The test listed in Table A-9 detects the solenoid Sensor's operating condition.

The Green LED will illuminate when the sensor is blocked.

If there are any problems with the Solenoid Sensor Board, the Red LED will blink 8 times.

**Table A-9** Solenoid Sensor Test Error Conditions

| DIP Switch Block Settings |                |                  |   |  |  |  |  |
|---------------------------|----------------|------------------|---|--|--|--|--|
| Solenoid Condition        | Red LED Status | Green LED Status | Causes and Conditions   |  |  |  |  |
| Solenoid Error            | 13 Flashes     | OFF              | A Solenoid Upper Sensor Board failure may have occurred. Check all harness and connectors. Exchange the Upper Sensor Board with a known good board. Refer to Section 4 regarding Circuit Board Removal. |  |  |  |  |



If diagnostic LED status is different from the Table A-9 listed states, contact JCM Technical Support.

## No. 7 General Sensor Test

The tests listed in Table A-10 detect the UBA's Sensors operational conditions.

To check the various sensor conditions, set the DIP Switches according to the sensor test desired and observe the LED illuminating conditions for the selected test listed in Table A-10.

Begin sensor testing as follows:

1. Set the UBA into the "Test Mode", by switching DIP Switch No. 8 to ON and applying power to the UBA.




*NOTE: If the diagnostic LED illuminating condition results are different from those listed in Table A-10 a fault condition is indicated.*

2. Now set DIP Switch 7 to ON and DIP Switch 8 to OFF to initially to start the first test.



*NOTE: Leave DIP Switch 7 ON throughout the Sensor Tests.*

Select the first Sensor to be tested from Table A-10, turn ON the appropriate test switches, and compare the LED illumination result to the expected adjacent listed Test Condition result.

**Table A-10** UBA General Sensor Test Settings**Initial DIP Switch Block Setting**

| Sensor Name                        | DIP Switch Conditions | Test Conditions  |
|------------------------------------|-----------------------|--|
| Entrance Sensor                    | 1 ON, & 2-6 OFF       | Open the Upper Guide to check the Entrance Sensor's condition. When the entrance sensor is blocked, the Green LED should illuminate. If the Green LED lights when the Entrance Sensor is blocked, the sensor's condition is normal.  |
| Centering Timing Sensor            | 1 ON, & 2-6 OFF       | Open the Upper Guide to check the Centering Timing Sensor's condition. When the Centering Timing Sensor is blocked, the RED LED should illuminate. If red LED lights when the Centering Timing Sensor is blocked, the sensor's condition is normal.  |
| Anti-Pullback Sensor               | 2 ON, & 1 + 3-6 OFF   | Open the Upper Guide as if to check Entrance Sensor's condition and block the Anti-Pullback Entrance Sensor. When the Anti-Pullback Entrance Sensor is blocked, the Green LED should illuminate. If Green LED is lights when the Anti-Pullback Entrance Sensor is blocked, the sensor's condition is normal. |
| Exit Sensor                        | 2 ON, & 1 + 3-6 OFF   | Block the Exit Sensor with a piece of paper or cardboard. When the Exit Sensor is blocked, the Red LED should illuminate. If Red LED lights when the Exit Sensor is blocked, the sensor's condition is normal.   |
| Anti-Pullback Home Position Sensor | 3 ON, & 1-2 + 4-6 OFF | Rotate the Anti-Pullback Roller with your fingers. When the Anti-Pullback Roller is in its Home position, the Green LED should illuminate. If the Green LED flickers ON and OFF while rotating the Anti-Pullback Roller, the sensor's condition is normal.   |
| Centering Home Position Sensor     | 3 ON, & 1-2 + 4-6 OFF | Move the Centering Mechanism with a Hexagonal Nut Driver. When the Centering Mechanism is in its Home position, the Red LED should illuminate. If the Red LED lights when the Centering mechanism is at its Home position, the sensor's condition is normal.   |
| Transport Motor Encoder Sensor     | 4 ON, & 1-3 + 5-6 OFF | Open the Upper Guide and move the belts forward to check the Transport Motor Encoder Sensor. When the Transport Encoder Sensor is blocked by an interrupter blade, the Green LED should illuminate. If the Green LED flickers On and OFF as the belts are moved, the sensor's condition is normal.           |
| Stacker Motor Encoder Sensor       | 4 ON, & 1-3 + 5-6 OFF | Rotate the Stacker gear with a finger. When the Stacker Encoder's Sensor is blocked by an interrupter blade, the Red LED should illuminate. If the Red LED flickers ON and OFF while rotating the gear, the sensor's condition is normal.  |
| Pusher Plate Home Position Sensor  | 5 ON, & 1-4 + 6 OFF   | Remove the Cash Box from the Frame Unit. When the Pusher Home Sensor's Left Arm is pushed, and the Pusher Home Sensor is blocked, the Green LED will be lit (ON). When the Pusher Home Sensor Arm is released, the sensor is unblocked and the Green LED will extinguish (go OFF).                           |
| Stacker Detection Sensor           | 5 ON, & 1-4 + 6 OFF   | Remove the Cash Box from the frame unit. When the Cash Box Seated Sensor's right lever is blocked, the Red LED should illuminate. If Red LED goes ON when the Cash Box is set into its fully seated position, the sensor's condition is normal   |

## No. 8 Bill Acceptance Test

The tests listed in Table A-11 detects the UBA's ability to properly accept bills.

Begin acceptance testing as follows:

1. Set DIP Switch No. 8 to ON and supply power to the UBA.
2. Set the remaining 6 DIP Switches according to the test selected in

Table A-11, and then turn DIP Switch No. 8 to ON to start the test.

3. Insert a bill into the UBA to begin the selected test.



*NOTE: Whenever the UBA is disassembled or new software is downloaded into memory, make sure to perform a Bill Acceptance Test afterwards.*

**Table A-11 UBA Bill Acceptance Test Error Conditions**

| With Cash Box                        | No Cash Box |
|--------------------------------------|-------------|
| <br><b>DIP Switch Block Settings</b> |             |

*NOTE: Refer to tables A13, A14 or A15 for error listings relating to this test.*

## No. 9 DIP Switch Test

The tests listed in Table A-12 reveal the correct DIP Switch operational conditions.

To begin the test perform the following:

1. Begin by setting all DIP Switches to ON and supply power to the UBA.
2. Check that both the Red and Green LEDs light as indicated in Table A-12 Step No. 1.

**Table A-12 DIP Switch Test Steps**

| Step No. | DIP Switch Setting | LED Status |       |
|----------|--------------------|------------|-------|
|          |                    | Red        | Green |
| 1        |                    | ON         | ON    |
| 2        |                    | OFF        | OFF   |
| 3        |                    | OFF        | ON    |
| 4        |                    | ON         | OFF   |
| 5        |                    | ON         | ON    |

3. Set Switch No. 8 to OFF as indicated in Table A-12 Step No. 2. The LEDs should both turn OFF
4. Set Switches 2, 4, and 6 to OFF as indicated in Table A-12 Step No. 3.
5. Set Switches 2, 4, and 6 to ON and Switches 1, 3, 5 and 7 to OFF as indicated in Table A-12 Step No. 4. The Red LED should light (go ON) and the Green LED should go OFF.
6. Set all remaining switches to OFF as indicated in Table A-12 Step No. 5. Both the Green and Red LED should now light.



If any diagnostic LED status condition is different from those listed in the Table A-12 Steps, a DIP Switch and/or CPU Board failure may have occurred. Refer to Section 4 regarding Circuit Board Removal. If the error can not be resolved, contact JCM Technical Support.

## LED Diagnostics Codes

### Malfunction LED Error Codes

Table A-13 lists the possible Malfunction LED Error Codes that can exist when a fault condition occurs.

**Table A-13** Malfunction LED Error Codes

| LED Status |           | Error  | Causes and Solutions   |
|------------|-----------|--|--|
| Red LED    | Green LED |  |  |
| 1 Flash    | ON        | Boot ROM error   | Change the CPU Board. Refer to Section 4 regarding Circuit Board Removal.  |
| 2 Flashes  | ON        | 1. Incorrect external ROM contents or empty program<br>2. No program in the external Flash ROM | Change the CPU Board. Refer to Section 4 regarding Circuit Board Removal.  |
| 3 Flashes  | ON        | Internal RAM error   | Change the CPU Board. Refer to Section 4 regarding Circuit Board Removal.  |
| 4 Flashes  | ON        | External RAM error   | Change the CPU Board. Refer to Section 4 regarding Circuit Board Removal.  |
| 5 Flashes  | ON        | Missing Boot EPROM   | In UBA-14/24 Units.  |
| 1 Flash    | OFF       | Cash Box Full  | Empty the Cash Box and re-install.   |
| 2 Flashes  | OFF       | Stacker Pusher Mechanism fault (Transport Jam Type 1)  | Stacker motor may be corrupted. Change the motor if defective. A Stacker Encoder Board failure may have also occurred. Check all harnesses and connectors. Exchange the Stacker Encoder Board and/or CPU Board if required with a known good board. Refer to Section 4 regarding Disassembly Instructions and Circuit Board Removal.   |
| 3 Flashes  | OFF       | Transport Jam Type 2   | An Exit Sensor Board failure may have occurred. Check all harnesses and connectors. Exchange the Exit Sensor Board and/or CPU Board if required with a known good board. Refer to Section 4 regarding Circuit Board Removal.   |
| 4 Flashes  | OFF       | Stacker Encoder signal fault or an Acceptor Jam  | A Stacker Encoder Sensor failure may have occurred. Check all lenses for dirt or scratches. To clean the lenses and sensors, refer to Section 2 regarding Preventive Maintenance. Check all harnesses and connectors. A Lower Sensor Board failure may have occurred. Exchange the Lower Sensor Board if required with a known good board. Refer to Section 4 regarding Circuit Board Removal. |
| 5 Flashes  | OFF       | Transport Motor speed error  | The Transport Motor Speed Encoder Sensor does not detect motor rotation or requires sensor adjustment. Check all harnesses and connectors. A Motor or CPU Board failure may have occurred. Exchange the Motor and/or CPU Board with a known good motor or board. Refer to Section 4 regarding Disassembly Instructions and Circuit Board Removal.  |
| 6 Flashes  | OFF       | Transport Motor failure  |  |
| 7 Flashes  | OFF       | Sensor Failure   | Replace either the Upper or Lower Sensor Board.  |
| 8 Flashes  | OFF       | Communications Failure   | A communications failure between the Upper Sensor Board and the CPU Board. Replace either the Upper Sensor Board and/or the CPU Board. Check that all cables are properly connected.   |

**Table A-13 Malfunction LED Error Codes (Continued)**

| LED Status |           | Error                              | Causes and Solutions  |
|------------|-----------|------------------------------------|---|
| Red LED    | Green LED |                                    |   |
| 9 Flashes  | OFF       | Anti-Pullback Unit Error           | An Anti-Pullback Home Sensor Board and/or a Lower Sensor Board failure may have occurred. Check all harnesses and connectors. Exchange the Anti-Pullback Home Sensor Board and/or a Lower Sensor Board with a known good board. Refer to Section 4 regarding Circuit Board Removal. |
| 10 Flashes | OFF       | Cash Box Error                     | Cash Box not seated or not present. A Cash Box Sensor Board failure may have occurred. Check all harness and connectors. Exchange the Cash Box Sensor Board and/or CPU Board if required with a known good board. Refer to Section 4 regarding Circuit Board Removal.               |
| 11 Flashes | OFF       | ICB Module Error                   | ICB Module missing, or requires replacement.  |
| 12 Flashes | OFF       | Cheated                            | Sensor blocked at an improper time.   |
| 13 Flashes | OFF       | Centering Mechanism Solenoid Error | A Solenoid or an Upper Sensor Board failure may have occurred. Check all harness and connectors. Exchange the Upper Sensor Board with a known good board. Refer to Section 4 regarding Disassembly Instructions and/or Circuit Board Removal.                                       |
| 14 Flashes | OFF       | Centering Mechanism Error          | A Centering Mechanism Home Sensor Board and/or CPU Board failure may have occurred. Check all harnesses and connectors. Exchange the Centering Mechanism Home Sensor Board with a known good board. Refer to Section 4 regarding Circuit Board Removal.                             |



If diagnostic LED status is different from the Table A-13 listed states, contact JCM Technical Support.

## Initialization LED Error Codes

Table A-14 lists the possible Initialization LED Error Codes that can exist when a fault condition occurs during a UBA initial start-up.

**Table A-14** ICB Initialization Errors

| LED Status  |           | Error       | Causes and Solutions   |
|-------------|-----------|-------------|--|
| Red LED     | Green LED |             |  |
| 3 Flashes   | OFF       | ICB Module  | ICB disabled or Cash Box is Active.  |
| 5 Flashes   | OFF       | Calibration | New Processor Board, or Calibration is correct. Re-calibrate the Sensors (See "Calibration Procedures" on page 6-4 in Section 6 of this Service Manual). |
| 11 Flashes  | OFF       | ICB Module  | Intelligent Cash Box (ICB) Communications Error (Failure Type 02).   |
| 12 Flashes  | OFF       | ICB Module  | Intelligent Cash Box (ICB) Check Sum Error (Failure Type 07). Memory partially cleared.  |
| 13 Flashes* | OFF       | ICB Module  | Intelligent Cash Box (ICB) Installed with data from another machine (i.e., data not cleared) (Failure Type 08)*.   |
| 14 Flashes  | OFF       | ICB Module  | Intelligent Cash Box (ICB) not initiated (Failure Type 09). Memory not properly cleared.   |
| 15 Flashes  | OFF       | ICB Module  | Intelligent Cash Box (ICB) Module Error (Failure AF). No ICB Module detected present on Validator.   |

\*. Occurs when three (3) rapid flashes are present when unit is initially powered-up indicating an ICB failure.



If diagnostic LED status is different from  
the Table A-14 listed states, contact JCM  
Technical Support.

## LED Reject Codes

Table A-15 lists the possible LED Reject Codes that can exist when a fault condition occurs.

**Table A-15** LED Reject Codes

| LED Status |            | Error  | Causes and Solutions  |
|------------|------------|--|---|
| Red LED    | Green LED  |  |   |
| OFF        | 1 Flash    | Slanted Bill Insertion                             | Re-insert the bill straight.  |
| OFF        | 2 Flashes  | Magnetic Sensor pattern error                      | Check Magnetic Head for dirt or scratches. To clean the Magnetic Head, refer to Section 2 regarding Preventive Maintenance. An Upper Sensor Board failure may have occurred. Check all harnesses and connectors. To change the Upper Sensor Board refer to Section 4 regarding Circuit Board Removal.   |
| OFF        | 3 Flashes  | Paper detected inside the Acceptor in standby mode | Remove the paper jam from the Acceptor path and clean the lenses. To clean the lenses and Sensors, refer to Section 2 regarding Preventive Maintenance. An Upper and/or Lower Sensor Board failure may have occurred. Check all harnesses and connectors. To change the Upper/Lower Sensor Board, refer to Section 4 regarding Circuit Board Removal. |
| OFF        | 4 Flashes  | Optical Sensor level error                         | An Upper and/or Lower Sensor Board failure may have occurred. Check all harnesses and connectors. To change the Upper/Lower Sensor Board, refer to Section 4 regarding Circuit Board Removal.   |
| OFF        | 5 Flash    | Banknote feed error Type 1                         | Banknote movement error (Timing). Check for worn or dirty Belts, poor quality Banknotes or Debris in the Bill Transport Path.   |
| OFF        | 6 Flashes  | Banknote identification error                      | Remove the Bill from the Acceptor and clean the lenses. To clean the lenses and sensors, refer to Section 2 regarding Preventive Maintenance. An Upper and/or Lower Sensor Board failure may have occurred. Check all harnesses and connectors. To change the Upper/Lower Sensor Board, refer to Section 4 regarding Circuit Board Removal.           |
| OFF        | 7 Flashes  | Barcode Read error                                 | An Upper and/or Lower Sensor Board failure may have occurred. Check all harnesses and connectors. To change the Upper/Lower Sensor Board, refer to Section 4 regarding Circuit Board Removal.   |
| OFF        | 8 Flashes  | Double Note or Ticket error                        | Check all bill path sensors.  |
| OFF        | 9 Flashes  | Inhibited Bill                                     | Check and set DIP switches properly. Refer to Section 1 regarding Component Names, and Section 6 referencing Software Specifications/Requirements.  |
| OFF        | 10 Flashes | Return Bill  | Bill inhibited by host machine.   |
| OFF        | 11 Flashes | Reserved   | N/A   |
| OFF        | 12 Flashes | Banknote feed error                                | Check all bill path sensors.  |
| OFF        | 13 Flashes | Banknote length error                              | Check all belts and rollers in the Transport path. To clean the belts and rollers, refer to Section 2 regarding Preventive Maintenance. To change the belts and rollers, refer to Section 4 regarding Disassembly Instructions.   |
| OFF        | 14 Flashes | Photo Pattern error                                | Check for dirty/clouded Lenses and clean the Lenses. To clean the lenses, refer to Section 2 of this Service Manual regarding Preventive Maintenance Procedures.  |
| OFF        | 15 Flashes | UV Sensor error                                    | Clean the UV Sensor and the White Reflecting Block below the Sensor. An Upper Sensor Circuit Board failure may have occurred. To change an Upper Sensor Circuit Board, refer to Section 4 of this Service Manual regarding Circuit Board Removal.   |



If diagnostic LED status is different from the Table A-15 listed states, contact JCM Technical Support.

THIS PAGE INTENTIONALLY LEFT BLANK

# UBA® Series

## Universal Bill Acceptor (UBA-1x-SS & UBA-x4-SS/SU)

### Appendix B

#### B GLOSSARY

##### A

- 1 **Acceptor** – a term used in Communications Section 3 referencing functions sent to, and received from the Bill Acceptor by software commands... See Page 1-1
- 2 **Anti-Pullback** – a method of preventing Banknotes (Bills) from being illegally removed from a Validator using a string, wire or transparent tape to retrieve it once it has been accepted by the Unit... See Page 4-8
- 3 **Anti-Pullback Mechanism** – the rotating drum located in the rear portion of the transport to prevent a Banknote (Bill) from being retrieved by an attached piece of string, wire or transparent tape  
... See Page 1-6
- 4 **Automatic Centering** – a mechanism for straightening an incorrectly inserted Banknote (Bill) prior to being read by the sensors... See Page 1-6

##### C

- 5 **Country Codes** – specific codes given to a country to identify its currency type...  
See Page 1-12
- 6 **CPU** – an acronym for Central Processing Unit... See Page 4-3

##### D

- 7 **DIP Switch** – Dual Inline Package Switch – a printed circuit board mountable two-position slide switch package containing up to 16 individual switches... See Page 2-10
- 8 **Downloader** – a proper name given to a specific UBA Flash EPROM programming application (i.e., UBA Downloader V1.11)... See Page 6-2

##### E

- 9 **E-Clip** – a semicircular clip resembling the capital letter “E”, designed to fit into a shaft groove to retain a component in place... See Page 4-1

##### F

- 10 **Flash Memory** – electronically programmable memory integrated circuits that can be reused without requiring special erasure procedures... See Page 6-1

##### I

- 11 **Identification Sensor** – optical sensors used for reading images on Banknotes (Bills) for comparison to recorded known image information... See Page A-1

##### M

- 12 **Magnetic Sensor** – a sensor used to detect the magnetic ink present on certain Banknote (Bill) denominations... See Page A-1

## P

- 13 **Photo-coupler isolation** – an LED and photo sensor combination utilized to isolate electrical signals... See Page 1-7
- 14 **Pictographs** – small internationally recognized safety and attention symbols placed to the left of Notes, Cautions and Warnings throughout the Manual... See Page 1-1
- 15 **Pusher Mechanism** – a device used to stack received Banknotes (Bills) into the Cash Box ... See Page 4-12

## R

- 16 **RS-232C Communication** – a common serial data communication standard protocol ... See Page 1-7

## S

- 17 **Sensor** – a Photo Sensitive Device and LED combination designed to detect timing and movement events... See Page 4-4
- 18 **Solenoid** – an electro-magnetically retracting piston that mechanically moves a lever arm or other actuator within the UBA... See Page 4-11

## T

- 19 **Transport Unit** – the upper portion of a UBA that moves a Banknote (Bill) past the various Sensors present in the Unit... See Page 4-2

## U

- 20 **UBA** – an acronym for Universal Bill Acceptor... See Page 1-1
- 21 **USB** – an acronym for Universal Serial Bus... See Page 2-8.

Universal Bill Acceptor (UBA-1x-SS & UBA-x4-SS/SU)



925 Pilot Road, Las Vegas, Nevada 89119

Office: (800) 683-7248, Tech. Support: (702) 651-3444, FAX: (702) 651-0214  
E-mail: [techsupport@jcm-american.com](mailto:techsupport@jcm-american.com) <http://www.jcm-american.com>

## UBA SYSTEM WIRING DIAGRAMS




Figure 5-2 UBA-10-SS Bill Acceptor System Wiring Diagram

PAGE 5-4 IS INTENTIONALLY BLANK

## System Wiring Diagrams (Continued)




Figure 5-3 UBA-11/12-SS Bill Acceptor System Wiring Diagram

PAGE 5-6 IS INTENTIONALLY BLANK

## System Wiring Diagrams (Continued)





Figure 5-4 UBA-14-SS &amp; UBA-24-SS/SU External Connector Interface Circuit Wiring Diagram

PAGE 5-8 IS INTENTIONALLY BLANK

**System Wiring Diagrams (Continued)****Figure 5-5** UBA-14/24 Optional Conversion Board Interface Circuit Wiring Diagram

PAGE 5-10 IS INTENTIONALLY BLANK